



# DS-K3G225(L)X Series Tripod Turnstile

User Manual

## Legal Information

### About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website ( <https://www.hikvision.com> ). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

### About this Product

- This product can only enjoy the after-sales service support in the country or region where the purchase is made.
- If the product you choose is a video product, please scan the following QR code to obtain the "Initiatives on the Use of Video Products", and read it carefully.



### Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

### LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR

IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

**© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.**



## Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss.

The precaution measure is divided into Dangers and Cautions:

**Dangers:** Neglecting any of the warnings may cause serious injury or death.

**Cautions:** Neglecting any of the cautions may cause injury or equipment damage.

	
<b>Dangers:</b> Follow these safeguards to prevent serious injury or death.	<b>Cautions:</b> Follow these precautions to prevent potential injury or material damage.

### **Danger:**

- All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.
- Please use the power adapter, which is provided by normal company. The power consumption cannot be less than the required value.
- Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.  
If the top caps should be open and the device should be powered on for maintenance, make sure:
  1. Power off the fan to prevent the operator from getting injured accidentally.
  2. Do not touch bare high-voltage components.
  3. Make sure the switch's wiring sequence is correct after maintenance.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
- When the product is installed on wall or ceiling, the device shall be firmly fixed.
- If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.
- Do not ingest battery, Chemical Burn Hazard.  
This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.  
Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)

### **Cautions:**

- Stainless steel may be corroded in some circumstances. You need to clean and care the device by using the stainless steel cleaner. It is suggested to clean the device every month.
- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Do not place the device in extremely hot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- The device cover for indoor use shall be kept from rain and moisture.
- Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
- Please use the provided glove when open up the device cover, avoid direct contact with the device cover, because the acidic sweat of the fingers may erode the surface coating of the device cover.
- Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.
- Please keep all wrappers after unpack them for future use. In case of any failure occurred, you need to return the device to the factory with the original wrapper. Transportation without the original wrapper may result in damage on the device and lead to additional costs.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.
- Biometric recognition products are not 100% applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.
- Do not stay in the lane when the device is rebooting.
- RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
- SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.
- The instructions shall require connection of the equipment protective earthing conductor to the installation protective earthing conductor.

# Contents


<b>Chapter 1 Overview .....</b>	<b>1</b>
1.1 Introduction .....	1
1.2 Main Features .....	2
<b>Chapter 2 System Wiring .....</b>	<b>3</b>
<b>Chapter 3 Install Pedestals .....</b>	<b>6</b>
<b>Chapter 4 General Wiring .....</b>	<b>8</b>
4.1 Components Introduction .....	8
4.2 Wiring Electric Supply .....	9
<b>Chapter 5 Terminal Description .....</b>	<b>12</b>
5.1 General Wiring .....	12
5.2 Lane Control Board Terminal Description .....	13
5.3 Access Control Board Terminal Description (Optional) .....	14
5.4 Loudspeaker Board Terminal Description (Optional) .....	16
5.5 Card Reader .....	17
5.6 RS-485 Wiring .....	18
5.7 Alarm Input Wiring .....	19
5.8 Exit Button Wiring .....	20
<b>Chapter 6 Device Settings via Button .....</b>	<b>21</b>
6.1 Configuration via Button .....	21
6.2 Initialize Device .....	23
<b>Chapter 7 Activation .....</b>	<b>24</b>
7.1 Activate via Web Browser .....	24
7.2 Activate via Mobile Web .....	24
7.3 Activate via SADP .....	25
7.4 Activate Device via iVMS-4200 Client Software .....	26
<b>Chapter 8 Operation via Web Browser .....</b>	<b>28</b>

8.1 Login .....	28
8.2 Forget Password .....	28
8.3 Quick Operation via Web Browser .....	28
8.3.1 Time Settings .....	28
8.4 Person Management .....	29
8.5 Turnstile .....	30
8.5.1 Overview .....	30
8.5.2 Search Event .....	31
8.5.3 Access Control Settings .....	32
8.5.4 Turnstile .....	38
8.6 System and Maintenance .....	41
8.6.1 View Device Information .....	41
8.6.2 Set Time .....	42
8.6.3 Change Administrator's Password .....	42
8.6.4 Online Users .....	43
8.6.5 View Device Arming/Disarming Information via PC Web .....	43
8.6.6 Network Settings .....	43
8.6.7 Set Audio Parameters on PC Web .....	47
8.6.8 Set Wiegand Parameters via PC Web .....	47
8.6.9 Serial Port Settings .....	48
8.6.10 Customize Audio Content .....	49
8.6.11 Upgrade and Maintenance .....	50
8.6.12 Device Debugging .....	52
8.6.13 Test Protocol via PC Web .....	52
8.6.14 Set Network Penetration Service via PC Web .....	53
8.6.15 Component Status .....	53
8.6.16 View Log via PC Web .....	54
8.6.17 Certificate Management .....	54

<b>Chapter 9 Configure the Device via the Mobile Web .....</b>	<b>57</b>
9.1 Login .....	57
9.2 Overview .....	57
9.3 Configuration .....	59
9.3.1 Turnstile Basic Parameters .....	59
9.3.2 Person Management .....	60
9.3.3 View Device Basic Information .....	62
9.3.4 Set Device Time .....	62
9.3.5 User Management .....	64
9.3.6 Network .....	64
9.3.7 Event Search .....	67
9.3.8 Set Audio .....	67
9.3.9 Access Control Settings .....	67
9.3.10 People Counting Settings .....	73
9.3.11 Other Settings .....	74
9.3.12 Upgrade and Maintenance .....	74
9.3.13 Log Out .....	75
9.3.14 Open Source Software Licenses .....	75
9.3.15 View User Document .....	75
<b>Chapter 10 Other Platforms to Configure .....</b>	<b>77</b>
<b>Appendix A. Event and Alarm Type .....</b>	<b>78</b>
<b>Appendix B. Error Code Description .....</b>	<b>79</b>

## Chapter 1 Overview

### 1.1 Introduction



By adopting the turnstile integratedly with the access control system, person should authenticate to pass through the lane via presenting cards, face, or QR code, etc. It is widely used in attractions, office, construction sites, residences and other indoor scenes.

### **1.2 Main Features**

- Bidirectional (Entering/Exiting) lane.
- Support remote control and management by HCP software.
- High-brightness LED indicates the entrance/exit and passing status.
- Fire alarm passing: When triggered, the arms will be dropped automatically for emergency evacuation.
- Support PC web configuration.
- Support ISAPI protocol for 3rd party integration development.

## Chapter 2 System Wiring

The preparation before installation and general wiring.

### Steps

1. Draw a central line on the installation surface of the left or right pedestal.
2. Draw other parallel lines for installing the other pedestals.



### Note

The distance between the nearest two line is 783 mm.

3. Slot on the installation surface and drill installation holes after determining the hole positions.  
Put 4 expansion bolts of M12\*150 for each pedestal.
4. Bury cables. Each lane buries 1 high voltage cable. For details, see the system wiring diagram below.




Figure 2-1 System Wiring

**Note**

- High voltage: AC power input
  - The suggested inner diameter of the high voltage conduit is larger than 30 mm.
  - The external AC power cord should be double-insulated.
  - Before digging holes, evaluate the thickness of the installation surface to avoid puncturing.
  - The network cable must be CAT5e or the network cable has better performance.
  - If the usage scenarios of the equipment include kindergarten and primary school, it is recommended to design dedicated turnstiles for young children and lower grade students to reduce the safety risks.
- If there is a scene where children pass through alone, it is recommended to use a children's bracket for face recognition terminal installation. When installing, it is recommended to

## DS-K3G225(L)X Series Tripod Turnstile User Manual

---

choose a low angle installation or an external vertical children's bracket. The vertical children's bracket is recommended to be installed about 0.5 meters in front of the turnstile.

---

## Chapter 3 Install Pedestals

### Before You Start


Prepare for the installation tools, check the device and the accessories, and clear the installation base.

### Steps

---

#### Note

- Make sure the device is installed on flat surface. The foundation should be hard and the thickness should exceeds the length of the expansion bolt.
  - Make sure the device is powered off during installation and other operations.
  - The installation tools are put inside the package of the pedestal.
  - In order to prevent stainless steel from rusting due to dirt during the installation, it is recommended to tear off the protective film after the device is installed.
  - There may be residual glue at the film cutting position, and it is recommended to wipe the glue with WD-40 protective liquid after tearing the film.
  - Indoor use only. Do not immerse the pedestal in the water.
  - If the installation area is close to the wall, make sure the distance between the pedestal and the wall should be more than 20 mm (60 mm if with face recognition terminals), or you might cause damage to the device or cannot open the pedestal's top panel.
  - Do not apply a force exceeding 50 kg on the arm.
-



**Figure 3-1 Dimension**

1. Prepare installation tools, check the components, and clean the installation base.
2. Align the pedestals with the pre-buried expansion bolts, and remove the top cover with the key.
3. Loosen four screws on the top with the screwdriver and remove the maintenance door on both sides.

Scan the QR Code to view the installation and wiring guide video.



## Chapter 4 General Wiring

---

### Note

- After maintenance, you should close the water-proof cover over the high voltage module.
  - When you should maintain or disassemble the high voltage modules, you should remove the entire high voltage modules and maintain it outside the turnstile. You should unplug the cables that connected to the peripherals before maintenance to avoid destroy of the device.
- 

### 4.1 Components Introduction

By default, basic components of the turnstile are connected well. The pedestals can communicate by wiring the interconnecting cables. And the turnstile supports wiring the AC electric supply for the whole system's power supply.

---

### Note

The voltage fluctuation of the electric supply is between 100 VAC and 240 VAC, 50 to 60 Hz.

---


The picture displayed below describes each component's position on the turnstile.

---

### Note

The diagram is for reference only.

---




**Figure 4-1 Component Introduction**


## 4.2 Wiring Electric Supply

Wire electric supply with the power switch or power adapter in the pedestal. Terminal L (brown) and terminal N (Blue) are on the switch, while terminal PE should connect to a ground wire (yellow and green wire).

For product with power switch, the wiring diagram is as follows:



For product with power adapter, the wiring diagram is as follows:



---

**⚠ Warning**

Terminal PE should connect to a ground wire to avoid hazard when people touching the device.

---

---

 **Note**

- The cable bare part should be no more than 8 mm. If possible, wear an insulation cap at the end of the bare cable. Make sure there's no bare copper or cable after the wiring.
  - The Terminal L and the Terminal N cannot be wired reversely. Do not wire the input and output terminal reversely.
  - To avoid people injury and device damage, when testing, the ground resistance of the equipotential points should not be larger than 2  $\Omega$ .
-

## Chapter 5 Terminal Description

### 5.1 General Wiring

The general wiring of lane control board, access control board and card reader.




Figure 5-1 General Wiring

#### Note

- The power cable from power supply to the main lane control board has been connected. You will need to prepare the 14AWG power cable to connect the AC power input to power supply.
- Barrier opens at the entrance/exit: connect to BTN1/BTN2 and GND.
- The RS-485 terminal corresponded port ID on the web is as follows:


**Table 5-1 RS-485 Connection Content**

RS-485 ID	Port ID on Web	Default Connection
RS-485A	Port 3	QR Code Scanner (Entrance)
RS-485B	Port 4	QR Code Scanner (Exit)
RS-485C	Port 5	Card Reader (Entrance)
RS-485D	Port 6	Card Reader (Exit)

## 5.2 Lane Control Board Terminal Description

The lane control board contains power input interface, exit button and fire input interface, access control board interface, debugging port, indicator interface, etc.

The picture displayed below is the lane control board diagram.



**Figure 5-2 Lane Control Board (Front)**






Figure 5-3 Lane Control Board (Rear)

### 5.3 Access Control Board Terminal Description (Optional)

Access control board is mainly used for authority identification in places with high security levels such as public security or judicial place, external device accessing, and communication with the upper platform and lane controller.



**Note**

- The SOC and MCU serial port are for maintenance and debugging use only.
- Press the Reset button for 5 s and the device will start to restore to factory settings.

The wiring diagram of extended interface of access control board is shown as follows.





Figure 5-4 Wring Diagram of BUS3 Interface

## 5.4 Loudspeaker Board Terminal Description (Optional)

The loudspeaker board contains the sub-1G antenna interface, lane control board interface, loudspeaker interface and debugging port.



**Figure 5-5 Loudspeaker Board Terminal**

## 5.5 Card Reader

The card reader can be connected to the BUS4 of the access board.




Figure 5-6 Card Reader

## 5.6 RS-485 Wiring

The RS-485 interfaces on the access control board and sub optional board are suggested to connect with the face recognition module or the card reader. Here takes connecting with a card reader as an example.

**Note**

- If there are other RS-485 devices connecting, the ID of the RS-485 cannot be conflicted.
- The connected 12 V power interface for the face recognition terminal cannot be connected with other 12 V devices.




Figure 5-7 Wiring RS-485

### 5.7 Alarm Input Wiring

On the main lane control board, you can wire the fire alarm input interface.




Figure 5-8 Remaining Open




Figure 5-9 Remaining Closed

## 5.8 Exit Button Wiring

The main and sub lane control board each has 1 button interface, which can be connected to exit button or face recognition device.




Figure 5-10 Exit Button Wiring

---

**Note**


- The face recognition devices are powered via 12 VDC power output interface of the main and sub lane control board.
  - Barrier open at the entrance: connect to BTN1 and GND.
  - Barrier open at the exit: connect to BTN2 and GND.
-

## Chapter 6 Device Settings via Button

### 6.1 Configuration via Button

#### Button Description

The buttons are on the lane control board.



**Figure 6-1 Button**

#### Exit Button

- Single press to open the gate from the entrance position.
- Double press to open the gate from the exit position.

#### Parameter Configuration Button

- LEFT: Press to add ten to configuration data
- RIGHT: Press to add one configuration data
- CANCEL: Return to the level-1 menu, or exit the configuration from the level-1 menu
- OK: Confirm the data, or enter configuration mode, or enter the submenu

## Note

- Configuration data is displayed by two digital tubes.
- Level-1 Menu: If the decimal point on the right is on, it indicates the level-1 menu. The number represents the configuration item number.
- Level-2 Menu: if the decimal point in the middle is on, it indicates the level -2 menu. The number represents the parameters of a configuration item.

## Button Configuration Procedure




Figure 6-2 Procedure


Steps:

1. Enter the configuration mode. The number of 1 will show up on the right side of the screen and the device is ready for configuration.
2. Press **LEFT** and **RIGHT** to set the configuration No. Press **OK** to enter the level-2 menu and view the parameters. Press **CANCEL**, or conduct no operation for 5 s to cancel configuration.
3. Press **LEFT** and **RIGHT** to set the parameters at your needs. Press **OK** to save the changes or press **CANCEL** back to configuration No. setting without saving changes. Conduct no operations for 5 s to cancel configuration.

### 6.2 Initialize Device

#### Steps

1. Hold the initialization button on the access control board for 5 s.



**Figure 6-3 Initialization Button Position**

2. The device will start restoring to factory settings.
3. When the process is finished, the device will beep for 3 s.

---

#### **Caution**

The initialization of the device will restore all the parameters to the default setting and all the device events are deleted.

---

#### **Note**

Make sure no persons are in the lane when powering on the device.

---

## Chapter 7 Activation

You should activate the device before the first login. After powering on the device, the system will switch to Device Activation page.

Activation via the device, SADP tool and the client software are supported.

The default values of the device are as follows:

- The default IP address: 192.0.0.64
- The default port No.: 8000
- The default user name: admin

### 7.1 Activate via Web Browser

You can activate the device via the web browser.

#### Steps

1. Enter the device default IP address (192.0.0.64) in the address bar of the web browser, and press **Enter**.



Make sure the device IP address and the computer's should be in the same IP segment.

2. Create a new password (admin password) and confirm the password.



**STRONG PASSWORD RECOMMENDED**-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.



Characters containing admin and nimda are not supported to be set as activation password.

3. Click **Activate**.
4. Edit the device IP address. You can edit the IP address via the SADP tool, the device, and the client software.

### 7.2 Activate via Mobile Web

You can activate the device via mobile web.

### Steps

1. Connect to the device hotspot with your mobile phone by entering the hotspot password.

---

#### Note

- For inactive devices, hotspot is enabled by default.
- The default hotspot password is the device serial number.

---

The login page will pop up.

2. Create a new password (admin password) and confirm the password.

---

#### Caution

**STRONG PASSWORD RECOMMENDED**-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

---

#### Note

Characters containing admin and nimda are not supported to be set as activation password.

3. Click **Activate**.
4. Edit the device IP address. You can edit the IP address via the SADP tool, the device, and the client software.

## 7.3 Activate via SADP

SADP is a tool to detect, activate and modify the IP address of the device over the LAN.

### Before You Start

- Get the SADP software from the supplied disk or the official website <http://www.hikvision.com/en/>, and install the SADP according to the prompts.
- The device and the PC that runs the SADP tool should be within the same subnet.

The following steps show how to activate a device and modify its IP address. For batch activation and IP addresses modification, refer to *User Manual of SADP* for details.


### Steps

1. Run the SADP software and search the online devices.
2. Find and select your device in online device list.
3. Input new password (admin password) and confirm the password.

## Caution

**STRONG PASSWORD RECOMMENDED**-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

### 4. Click **Activate** to start activation.



The screenshot shows the SADP web interface. On the left, a table lists devices with columns for ID, Device Type, Security, IP4 Address, Port, Software Version, IP4 Gateway, HTTP Port, and Device Serial No. Device 007 is highlighted with a red box and labeled 'Inactive' with the IP address 192.0.0.64. A red text annotation 'Select inactive device.' points to this row. On the right, the 'Activate the Device' sidebar is visible. It contains a message 'The device is not activated.' and a section for password input with fields for 'New Password', 'Strong', and 'Confirm Password'. A red box highlights these password fields, with a red text annotation 'Input and confirm password.' pointing to them. There is also an 'Activate' button at the bottom of the sidebar.

Status of the device becomes **Active** after successful activation.

### 5. Modify IP address of the device.

- 1) Select the device.
- 2) Change the device IP address to the same subnet as your computer by either modifying the IP address manually or checking **Enable DHCP**.
- 3) Input the admin password and click **Modify** to activate your IP address modification.

## 7.4 Activate Device via iVMS-4200 Client Software

For some devices, you are required to create the password to activate them before they can be added to the iVMS-4200 software and work properly.

### Steps

#### Note

This function should be supported by the device.

1. Enter the Device Management page.

2. Click  on the right of **Device Management** and select **Device**.

3. Click **Online Device** to show the online device area.

The searched online devices are displayed in the list.

4. Check the device status (shown on **Security Level** column) and select an inactive device.

5. Click **Activate** to open the Activation dialog.

6. Create a password in the password field, and confirm the password.

---



### Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the service provider and/or end-user.

---



### Note

Characters containing admin and nimda are not supported to be set as activation password.

---

7. Click **OK** to activate the device.

## Chapter 8 Operation via Web Browser

### 8.1 Login

You can login via the web browser or the remote configuration of the client software.



Make sure the device is activated. For detailed information about activation, see **[Activate via Web Browser](#)**.

---

Enter the device IP address in the address bar of the web browser and press **Enter** to enter the login page.

Enter the device user name and the password. Click **Login**.



5 failed password enterings will lock the device. You should try again after 30 min.

---

### 8.2 Forget Password

If you forget the password when logging in, you can change the password by email address or security questions.

On the login page, click **Forget Password**.

Select **Verification Mode**.

#### Security Question Verification

Answer the security questions.

#### E-mail Verification

1. Export the QR code and send it to ***pw\_recovery@hikvision.com*** as attachment.
2. You will receive a verification code within 5 minutes in your reserved email.
3. Enter the verification code into the verification code field to verify your identification.

Click **Next**, create a new password and confirm it.

### 8.3 Quick Operation via Web Browser

#### 8.3.1 Time Settings

Click  in the top right of the web page to enter the wizard page.

#### Device Time

Display the device time in real time.

### Time Zone

Select the device located time zone from the drop-down list.

### Time Synchronization Mode

#### NTP

You should set the NTP server's IP address, port No., and interval.

#### Manual

By default, the device time should be synchronized manually. You can set the device time manually or check **Sync. with Computer Time** to synchronize the device time with the computer's time.

### DST

You can enable DST, set and view the DST start time, end time and bias time.

Click **Complete** to save the settings.

## 8.4 Person Management

Click **Add** to add the person's information, including the basic information, certificate and authentication settings.

### Add Basic Information

Click **Person Management** → **Add** to enter the Add Person page.

Add the person's basic information, including the employee ID, the person's name, and person type.

If you select **Visitor** as the person type, you can set the visit times.

Click **Save** to save the settings.

### Set Permission Time

Click **Person Management** → **Add** to enter the Add Person page.

Enable **Long-Term Effective User**, or set **Validity Period** and the person can only has the permission within the configured time period according to your actual needs.

Click **Save** to save the settings.

### Add Card

Click **Person Management** → **Add** to enter the Add Person page.

Click **Add Card**, enter the **Card No.** and select the **Property**, and click **OK** to add the card.



#### Note

Up to 50 cards can be added.

---

Click **Save** to save the settings.

## Authentication Settings

Click **Person Management** → **Add** to enter the Add Person page.

Set **Authentication Type** as **Same as Device** or **Custom**.

Click **Save** to save the settings.

## Import/Export Person Data

### Export Person Data

You can export added person data for back-up or importing to other devices.

Click **Export** → **Export Person Data (Database)**, set an encryption password and confirm it. Click **OK**.



#### Note

- The person data will be downloaded to your PC.
  - The password you set will be required for importing the data file.
- 

### Importing Person Data

Click **Import** → **Import Person Data** and select the file.

Enter the encryption password to import and synchronize the person data to devices.

## 8.5 Turnstile

### 8.5.1 Overview

You can view the device component status, real-time event, person information, network status, basic information, and device capacity. You can also control the barrier remotely.

Function Descriptions:

#### Device Component Status

You can check if the device is working properly. Click **View More** to view the detailed component status.

#### Remote Control



The door is opened/closed/remaining open/remaining closed.

#### Real-Time Event

You can view the event Employee ID, Name, Card No., Event Type, Time, and Operation. You can also click **View More** to enter the search conditions, including the event type, employee ID, the name, the card No., the start time, and the end time, and click **Search**. The results will be displayed on the right panel.

#### Person Information

You can view the added and not added information of person and card.

### **Network Status**

You can view the network connection status.

### **Basic Information**

You can view the model, serial No. and firmware version.

### **Device Capacity**

You can view the person, card and event capacity.

## **8.5.2 Search Event**

Click **Turnstile** → **Event Search** to enter the page.

Event Types

Major Type

Sub Type

Employee ID

Name

Card No.

Start Time

End Time

**Figure 8-1 Search Event**

Enter the search conditions, including the event type, major and sub type, the employee ID, the name, the card No., the start time, and the end time, and click **Search**.

The results will be displayed on the right panel.

### 8.5.3 Access Control Settings

#### Set Door Parameters

Click **Turnstile** → **Parameter Settings** → **Door Parameters** .

Door No.

Door Name

Open Duration  s

Exit Button Type  Remain Closed  Remain Open

Door Remain Open Duration wi...  min

**Figure 8-2 Door Parameters Settings**

Set the parameters and click **Save** to save the settings after the configuration.

### Door No.

Select **Entrance** or **Exit** for settings.

### Door Name

You can create a name for the door.

### Open Duration

Set the door unlocking duration. If the door is not opened for the set time, the door will be locked.



### Note

The open duration ranges from 5 s to 60 s.

---

### Exit Button Type

You can set the exit button as **Remain Open** or **Remain Closed** according to your actual needs. By default, it is **Remain Open**.

### Door Remain Open Duration with First Person

Set the door open duration when first person is in. After the first person is authorized, it allows multiple persons access the door or other authentication actions.

## Set Authentication Parameters

Click **Turnstile** → **Parameter Settings** → **Authentication Settings** .

---



### Note

The functions vary according to different models. Refers to the actual device for details.

---

### Card Reader Parameter Configuration

Terminal

Terminal Type

Terminal Model

Enable Authentication Device

① Authentication Interval  s

① Alarm of Max. Failed Attem...

Communication with Controller ...  s

### Authentication Plan Configuration

Authentication  Card  Clear ...

	00	02	04	06	08	10	12	14	16	18	20	22	24
Sun													
Mon													
Tue													
Wed													
Thu													
Fri													
Sat													

The selected authentication mode should be supported by card reader.

**Figure 8-3 Authentication Settings**

Set the parameters and click **Save** to save the settings after the configuration.

#### Terminal

Choose **Entrance** or **Exit** for settings.

#### Terminal Type/Terminal Model

Get terminal description. They are read-only.

#### Enable Authentication Device

Enable the authentication function.

#### Authentication Interval

You can set the authentication interval of the same person when authenticating. The same person can only authenticate once in the configured interval. A second authentication will be failed.

## Alarm of Max. Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

## Max. Authentication Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

## Communication with Controller Every

When the access control device cannot connect with the card reader for longer than the set time, the card reader will turn offline automatically.



### Note

The authentication interval value ranges from 2 s to 255 s.

---

## Card Settings

### Set Card Type

Click **Turnstile** → **Parameter Settings** → **Card Settings** to enter the settings page.

Set the parameters and click **Save**.

#### Enable NFC Card

In order to prevent the mobile phone from getting the data of the access control, you can disable NFC card to increase the security level of the data.

#### Enable M1 Card

Enable M1 card and authenticating by presenting M1 card is available.

#### M1 Card Encryption

##### Sector

M1 card encryption can improve the security level of authentication.

Enable the function and set the encryption sector. By default, Sector 13 is encrypted. It is recommended to encrypt sector 13.

#### Enable EM Card

Enable EM card and authenticating by presenting EM card is available.



### Note

If the peripheral card reader supports presenting EM card, the function is also supported to enable/disable the EM card function.

---

#### Enable DESFire Card

The device can read the data from DESFire card when enabling the DESFire card function.

#### DESFire Card Read Content

After enable the DESFire card content reading function, the device can read the DESFire card content.

### **Enable FeliCa Card**

The device can read the data from FeliCa card when enabling the FeliCa card function.

### **Set Card No. Authentication Parameters**

Set the card reading content when authenticate via card on the device.

Go to **Turnstile → Parameter Settings → Card Settings** .

Select a card authentication mode and click **Save**.

#### **Card Authentication Mode**

##### **Full Card No.**

All card No. will be read.

##### **Wiegand 26 (3 bytes)**

The device will read card via Wiegand 26 protocol (read 3 bytes).

##### **Wiegand 34 (4 bytes)**

The device will read card via Wiegand 34 protocol (read 4 bytes).

##### **Corporate1000\_35/Corporate1000\_48/H10302\_37/10304\_37/H103130\_332CSN/ Wiegand\_56CSN/Wiegand\_58**

The device will read card via the other mode.

#### **Enable Reversed Card No.**

The read card No. will be in reverse sequence after enabling the function.

### **Event Linkage**

Set linked actions for events.

#### **Steps**

**1.** Click **Turnstile → Parameter Settings → Linkage Settings** to enter the settings page.

The screenshot shows a configuration window for 'General Linkage'. On the left, there are icons for adding, deleting, and editing, along with a red button labeled 'Add New Event and Card ...'. The main area is titled 'Event Source' and contains three radio button options for 'Linkage Type': 'Event Linkage' (selected), 'Card Linkage', and 'Link Employee ID'. Below these are two dropdown menus for 'Event Types', with 'Device Event' and 'No Memory Alarm for Unreport' selected. The 'Linkage Action' section below has four toggle switches: 'Buzzer Linkage', 'Door Linkage', 'Linked Alarm Output', and 'Linkage Audio Prompt', all of which are currently disabled. A red 'Save' button is positioned at the bottom center of the configuration area.

**Figure 8-4 Event Linkage**

2. Click + to set event source.

- If you choose **Linkage Type** as **Event Linkage**, you need to select event types from the drop-down list.
- If you choose **Linkage Type** as **Card Linkage**, you need to enter the card No. and select the card reader.
- If you choose **Linkage Type** as **Employee ID Linkage**, you need to enter the employee ID and select the card reader.

3. Set linkage action.

### **Door Linkage**

Enable **Door Linkage**, and set the door status **Entrance** and **Exit** for the target event.

### **Linked Alarm Output**

Enable **Linked Alarm Output**, check **Alarm Output 1** or **Alarm Output 2**, and set the alarm output status for the target event.

### **Linked Audio Prompt**

Enable **Linked Audio Prompt** and select the play mode.

- If you choose **TTS**, you need to set language and enter the prompt content.
- If you choose **Audio File**, you need to select an available audio file from the drop-down list or click **General Linkage Settings** to add a new audio file.

### **Linked Capture**

Enable **Linked Capture** and select entrance or exit to capture for the target event.

### Set Terminal Parameters

You can set terminal parameters for accessing.

Click **Turnstile → Parameter Settings → Terminal Parameters** .

You can set **Working Mode** as **Permission Free Mode** or **Access Control Mode**.

#### Permission Free Mode

The device only judge your credential is in the valid duration, and will not authenticate the permission.

Enable **Remote Verification → Verify Credential Locally** , the device will check permission but not estimate the plan template.

#### Access Control Mode

The access control mode is the device normal mode. You should authenticate your credential for accessing.

You can enable **Remote Verification** according to your actual needs. After enabling, you can verify remotely. And you can enable **Verify Credential Locally** according to your actual needs.

Click **Save** to save the settings after the configuration.

### Set Privacy Parameters

Set the event storage type.

Go to **Turnstile → Parameter Settings → Privacy Settings**

The event storage type is overwriting by default. The earliest 5% events will be deleted when the system detects the stored events has been over 95% of the full space.

## 8.5.4 Turnstile

### Basic Parameters

Set turnstile basic parameters.

#### Steps

1. Click **Turnstile → Turnstile Configuration → Basic Settings** to enter the page.

Channel Type Tripod Turnstile

Channel Model

Working Status Normal

Passing Mode  General Passing  Weekly Schedule

Entrance

Exit

**Figure 8-5 Basic Parameters**

**2.** View the **Channel Type**, **Channel Model** and **Working Status**.

**3.** Set the passing mode.

### **General Passing**

If you choose **General Passing**, you can select the barrier status for the entrance and exit from the drop-down list.

### **Weekly Schedule**

If you choose **Weekly Schedule**, you can set a weekly schedule for entrance and exit barriers.


**4.** Click **Save**.

## **People Counting**

Set people counting.

### **Steps**

**1.** Click **Turnstile** → **Turnstile Configuration** → **People Counting Settings** to enter the page.



**Figure 8-6 People Counting**

2. Enable **People Counting**.
3. Enable **Device Offline People Counting**, the device will count people numbers even if it is offline.
4. Enable **Passing Event Record**, the device will report passing event when people passing.
5. Select **People Statistics Type**.

**Invalid**

Disable people counting.

**Passing Detection**

The number of all passing people.

**Authentication Number**

The number of passing people verified through card swiping, etc.

6. **Optional:** Click **Clear** to clear all the people counting information.

## Other Settings

Set other parameters.

### Steps

1. Click **Turnstile** → **Turnstile Configuration** → **Other Settings** to enter the page.
2. Set parameters.

**Alarm Output Duration**

The alarm output duration ranges from 0 s to 3599 s. 0 indicates continuous output.

**Light Board Brightness**

Drag the block or enter the value to adjust the brightness. The larger the value, the brighter the light becomes.

### **Alarm Buzzing Duration**

Set the duration of alarm sound.

### **Anti-Passback Rule**

Set the anti-passback rule as **By Authentication Status** or **By Passing Status**.

#### **By Authentication Status**

The person should pass the authentication or the anti-passback will be failed.

#### **By Passing Status**

The person cannot pass the authentication and the anti-passback will be completed.

### **Memory Mode**

Multiple cards presenting for multiple person passing is allowable when enabling the memory mode. When the passing person's number exceeds the card presenting number, or after the latest person passing with no other person passing within the door open duration, the door will close automatically.

By default, it is disabled.

### **Fire Input Type**

In the normally open state, closing triggers fire protection. In the normally closed state, disconnection triggers fire protection.

3. Click **Save**.

## **8.6 System and Maintenance**

You can view the system information and the capacity. You can also upgrade the device, restore to factory settings, restore to default settings, and reboot the device.

### **8.6.1 View Device Information**

View the device name, language, model, serial No., version, number of channels, IO input, IO output, alarm input, alarm output, and device capacity, etc.

Click **System and Maintenance** → **System Configuration** → **System** → **System Settings** → **Basic Information** to enter the configuration page.

You can view the language, model, serial No., version, IO input, IO output, alarm input and alarm output number.

You can change **Device Name** and click **Save**.

Click **Upgrade** to upgrade the firmware version.

You can view the device capacity, including person, face, card and event.

## 8.6.2 Set Time

Set the device's time zone, synchronization mode, server address, NTP port, and interval.

Click **System and Maintenance** → **System Configuration** → **System** → **System Settings** → **Time Settings** .

Device Time 2024-06-17 19:57:14

Time Zone (GMT+08:00) Beijing, Urumqi, Singapore, Perth

Time Synchronization mode  NTP  Manual

Set Time 2024-06-17 19:56:52 Sync With Com...

DST

**Figure 8-7 Time Settings**

Click **Save** to save the settings after the configuration.

### Time Zone

Select the device located time zone from the drop-down list.

### Time Sync.

#### NTP

You should set the NTP server's IP address, port No., and interval.

#### Manual

By default, the device time should be synchronized manually. You can set the device time manually or check **Sync. with Computer Time** to synchronize the device time with the computer's time.

#### DST

You can set the DST start time, end time and bias time.

## 8.6.3 Change Administrator's Password

### Steps

1. Enter the password change page.
  - Click **System and Maintenance** → **System Configuration** → **System** → **User Management** → **User Management** and click .
  - Click **admin** → **Modify Password** at the upper right corner of the page.
2. Enter the old password and create a new password.
3. Confirm the new password.

#### 4. Click **Save**.



#### **Caution**

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the service provider and/or end-user.

---

### 8.6.4 Online Users

The information of users logging into the device is shown.

Go to **System and Maintenance** → **System Configuration** → **System** → **User Management** → **Online User** to view the list of online users.

### 8.6.5 View Device Arming/Disarming Information via PC Web

View device arming type and arming IP address.

Go to **System and Maintenance** → **System Configuration** → **System** → **User Management** → **Arming/Disarming Information** .

You can view the device arming/disarming information. Click **Refresh** to refresh the page.

### 8.6.6 Network Settings

#### **Set Basic Network Parameters**

Click **System and Maintenance** → **System Configuration** → **System** → **Network** → **Network Settings** → **TCP/IP** .

You can view the mac address and MTU.

Set the parameters and click **Save** to save the settings.

The screenshot shows a network configuration interface with the following elements:

- NIC Type:** A drop-down menu set to "Self-Adaptive".
- DHCP:** A toggle switch that is currently turned off.
- \* IPv4 Address:** A text input field.
- \* IPv4 Subnet Mask:** A text input field.
- \* IPv4 Default Gateway:** A text input field.
- IPv6 Mode:** Three radio buttons: "Manual" (selected), "DHCP", and "Route Advertisement".
- \* IPv6 Address:** A text input field containing "::".
- \* IPv6 Subnet Prefix Length:** A text input field containing "::".
- \* IPv6 Default Gateway:** A text input field containing "::".
- Mac Address:** A text input field.
- MTU:** A text input field containing "1500".
- DNS Server:** A section header.
- DHCP:** A toggle switch that is currently turned off.
- Preferred DNS Server:** A text input field.
- Alternate DNS Server:** A text input field.
- Save:** A red button at the bottom.

**Figure 8-8 Set TCP/IP**

## **NIC Type**

Select a NIC type from the drop-down list. By default, it is **Auto**.

## **DHCP**

If uncheck the function, you should set the IPv4 address, IPv4 subnet mask, IPv4 default gateway, Mac address, and MTU.

If you check the function, the system will allocate the IPv4 address, IPv4 subnet mask, the IPv4 default gateway automatically.

## **IPv6 Mode**

## Manual

Set the IPv6 address, IPv6 subnet prefix length and IPv6 default gateway manually.

## DHCP

The system will allocate the IPv6 address, IPv6 subnet prefix length and IPv6 default gateway automatically.

## Route Advertisement

A mechanism for automatic address configuration in the IPv6 protocol stack. The device can complete IPv6 address configuration as long as there are routers in the environment that can provide routing notification messages.

Click **View Route Advertisement** to view the IPv6 address list.

## DNS Server

---



Only when DHCP is enabled can DNS server be set.

---

Set the preferred DNS server and the alternate DNS server according to your actual need.

## Set Port via PC Web

Click **System and Maintenance** → **System Configuration** → **Network** → **Network Service** .

### HTTP

It refers to the port through which the browser accesses the device. For example, when the HTTP Port is modified to 81, you need to enter **http://192.0.0.65:81** in the browser for login.

### HTTPS

Set the HTTPS for accessing the browser. Certificate is required when accessing.

### HTTP Listening

The device can send alarm information to the event alarm IP address or domain name via HTTP protocol/HTTPS protocol. Edit the event alarm IP address or domain name, URL, port, and protocol.



The event alarm IP address or domain name should support the HTTP protocol/HTTPS protocol to receive the alarm information.

---

## Set OTAP via PC Web

Connect the device to the platform through the OTAP protocol to obtain device information, upload operation status and alarm information, restart and upgrade the device.

## Steps

1. Click **System and Maintenance** → **System Configuration** → **Network** → **Device Access** → **OTAP** .

Enable

\* Server IP Address

\* Port

\* Device ID

\* Encryption Key

Register Status ✘ Offline

More ▼

**Figure 8-9 Set OTAP**

2. Select central group.
3. Click to **Enable** OTAP.
4. Set **Server IP Address**, **Port**, **Device ID** and **Encryption Key**.
5. Click **More** to view the network type and access priority. Drag the operation icon upward or downward to adjust the network priority.
6. Click **Test** to ensure the device can connect to the server and register successfully. Refresh the page or restart the device to see the **Register Status**.
7. Click **Save**.

## Platform Access via PC Web

Platform access provides you an option to manage the devices via platform.

### Steps

1. Click **System and Maintenance** → **System Configuration** → **Network** → **Device Access** → **Hik-Connect** to enter the settings page.

---

#### **Note**

Hik-Connect is an application for mobile devices. With the App, you can view live image of the device, receive alarm notification and so on.

2. Check **Enable** to enable the function.
3. **Optional:** Check the checkbox of **Custom**, and you can set the server address by yourself.
4. Enter the verification code.
5. **Optional:** Check **Enable** to enable video encryption, set an encryption password and confirm it.

6. Click **More** to view the network type and access priority. Drag the operation icon upward or downward to adjust the network priority.
7. Click **View** to view device QR code. Scan the QR code to bind the account.

---

### **Note**

8 to 32 letters (a to z, A to Z) or numbers (0 to 9), case sensitive. You are recommended to use a combination of no less than 8 letters or numbers.

---

8. Click **Save** to enable the settings.

### 8.6.7 Set Audio Parameters on PC Web

#### Steps

1. Click **System and Maintenance** → **System Configuration** → **Video/Audio** → **Audio** .
2. Slide to enable **Enable Voice Prompt** and the voice prompt will be on on the device.
3. Set the output volume.

### 8.6.8 Set Wiegand Parameters via PC Web

You can set the Wiegand transmission direction.

#### Steps


---

### **Note**

Some device models do not support this function. Refer to the actual products when configuration.

---

1. Click **System and Maintenance** → **System Configuration** → **Access Configuration** → **Wiegand Settings** .



No.

Wiegand

Wiegand Direction

Wiegand Mode

**Figure 8-10 Wiegand Page**

2. Select **Entrance** or **Exit** as the card reader's direction.
3. Enable **Wiegand** to enable the Wiegand function.
4. Set a transmission direction.

#### **Input**

The device can connect a Wiegand card reader.

5. Select **Wiegand Mode** from the drop-down list.
6. Click **Save**.

---

## Note

If you change the peripheral, and after you save the device parameters, the device will reboot automatically.


---

## 8.6.9 Serial Port Settings

Set serial port parameters.

### Steps

1. Click **System and Maintenance** → **System Configuration** → **Access Configuration** → **Serial Port Configuration** .



Serial Port Type RS232

No. 1

Baud Rate 115200

Data Bit 8

Stop Bit  1  2

Parity  None  Odd Parity  Even Verification

Peripheral Type  QR Code Scanner  Disable

Peripheral Position  Entrance  Exit

External Device Model None

**Save**

**Figure 8-11 Serial Port Configuration**

2. Select a serial port No., and the corresponding serial port type will display automatically.
3. Set the serial port parameters.

### Baud Rate

Configure data transfer rate.

### Data Bit

Configure the number of bits to send data.

### Stop Bit

Select the end point for one frame of data.

### Parity

Select the serial communication error detection principle. You can choose to detect that the number of 1 of the data bits and check digits is odd or even, or that there is no check digit.

4. Set the **Peripheral Type**.
5. Set the **Peripheral Position** as **Entrance** or **Exit**.
6. You can view the external device model.
7. Click **Save**.

## 8.6.10 Customize Audio Content

Customize the output audio content when authentication succeeded and failed.

### Steps

1. Click **System and Maintenance** → **Preference** → **Prompt Schedule** .

The screenshot shows the 'Audio File Management' configuration interface. At the top left, there are links for '+ Add' and 'Audio File Management'. A red bar labeled 'Default' is visible. The main configuration area includes an 'Enable' toggle switch which is turned on. Below this, there are radio buttons for 'Appellation' with options: 'Name', 'Family Name', and 'None' (which is selected). There are two input fields for 'Time Period When Authentication Succeeded' and 'Time Period When Authentication Failed', each with a '+ Add Time Duration' button. At the bottom, there is a red 'Save' button.

**Figure 8-12 Customize Audio Content**

2. Enable the function.
3. Set the appellation.
4. Set the time period when authentication succeeded.
  - 1) Click **Add Time Duration**.
  - 2) Set the time duration.

---

### Note


If authentication is succeeded in the configured time duration, the device will broadcast the configured content.

- 3) Select the voice prompt type.
- 4) Enter the audio prompt content or select audio file.

---

### Note

You can click + **Audio File** or **Audio File Management** to add audio files.

- 5) **Optional:** Repeat substep 1 to 3.
  - 6) **Optional:** Click  to delete the configured time duration.
5. Set the time duration when authentication failed.
- 1) Click **Add Time Duration**.
  - 2) Set the time duration.

---

### Note


If authentication is failed in the configured time duration, the device will broadcast the configured content.

- 3) Select the voice prompt type.
- 4) Enter the audio prompt content or select audio file.

---

### Note

You can click + **Audio File** or **Audio File Management** to add audio files.

- 5) **Optional:** Repeat substep 1 to 3.
  - 6) **Optional:** Click  to delete the configured time duration.
6. Click **Save**.

## 8.6.11 Upgrade and Maintenance

Reboot device, restore device parameters, and upgrade device version.


### Reboot Device

Click **System and Maintenance** → **Maintenance** → **Restart** .

Click **Restart** to reboot the device.

### Upgrade

Click **System and Maintenance** → **Maintenance** → **Upgrade** .

Select an upgrade type from the drop-down list. Click  and select the upgrade file from your local PC. Click **Upgrade** to start upgrading.

---

### Note

Do not power off during the upgrading.

---

## Restore Parameters

Click **System and Maintenance** → **Maintenance** → **Backup and Reset** .

### Restore All

All parameters will be restored to the factory settings. You should activate the device before usage.

### Restore

The device will restore to the default settings, except for the network parameters and the user information.

## Import and Export Parameters

Click **System and Maintenance** → **Maintenance** → **Backup and Reset** .

### Export

Click **Export** to export the device parameters.



### Note

You can import the exported device parameters to another device.

---

### Import

Click  and select the file to import. Click **Import** to start import configuration file.

## Device Debugging

You can set device debugging parameters.

### Steps

1. Click **System and Maintenance** → **Maintenance** → **Device Debugging** .
2. You can set the following parameters.

#### Enable SSH

To raise network security, disable SSH service. The configuration is only used to debug the device for the professionals.

#### Print Log

You can click **Export** to export log.

#### Capture Network Packet

You can set the **Capture Packet Duration**, **Capture Packet Size**, and click **Start** to capture.

#### Debug Command Management

Select the command type **Quick Command** or enter the content of **Custom Command**.

Select the board type from the drop-down list, click **Send** to send the debug command, you can view the received command information of the device in **Execution Result**.

Click **End Debugging**, the device restores to normal operation status.



### Note

- To ensure the device performance, please click **End Debugging** to close the Debugging command
  - If you do not tap **End Debugging**, the device will end the debugging mode within 7×24 hours automatically.
- 

### 8.6.12 Device Debugging

You can set device debugging parameters.

#### Steps

1. Click **System and Maintenance** → **Maintenance** → **Device Debugging** .
2. You can set the following parameters.

#### Enable SSH

To raise network security, disable SSH service. The configuration is only used to debug the device for the professionals.

#### Print Log

You can click **Export** to export log.

#### Capture Network Packet

You can set the **Capture Packet Duration**, **Capture Packet Size**, and click **Start** to capture.

#### Debug Command Management

Select the command type **Quick Command** or enter the content of **Custom Command**.

Select the board type from the drop-down list, click **Send** to send the debug command, you can view the received command information of the device in **Execution Result**.

Click **End Debugging**, the device restores to normal operation status.




### Note

- To ensure the device performance, please click **End Debugging** to close the Debugging command
  - If you do not tap **End Debugging**, the device will end the debugging mode within 7×24 hours automatically.
- 

### 8.6.13 Test Protocol via PC Web

Select a protocol address, and enter the protocol to test. You can debug the device according to the response header and returned value.

Go to **System and Maintenance** → **Maintenance** → **Device Debugging** → **Protocol Testing**.



**Figure 8-13 Protocol Testing**

Select a protocol address, and enter the protocol. Click **Execute**.

Debug the device according to the response header and returned value.

## 8.6.14 Set Network Penetration Service via PC Web

When the device is deployed in the LAN, you can enable the penetration service to realize device remote management.

### Steps

1. Go to **System and Maintenance** → **Maintenance** → **Device Debugging** → **Network Penetration Service**.
2. Slide **Enable Penetration Service**.
3. Set **Server IP Address** and **Server Port**. Create **User Name** and **Password**.
4. **Optional**: You can set **Heartbeat Timeout**. The value range is 1 to 6000.
5. **Optional**: You can view the status of the penetration service. Click **Refresh** to refresh the status.
6. Click **Save**.



### Note

The penetration service will auto disabled after 48 h.

---

## 8.6.15 Component Status

You can view the status of different components.

## Main Lane Status

### Device Component

You can view the status of the access control board, lane control board, etc.

### Peripheral

You can view the status of the RS-485 card reader.

### Temperature

You can view the pedestal temperature.

### Movement

You can view the working status of motor encoder.

## Others

### Passing Mode

You can view the entrance and exit mode.

### Input and Output Status

You can view the status of the event input, alarm output and fire alarm.

### Other Status

You can view the status of the barrier.

## 8.6.16 View Log via PC Web

You can search and view the device logs.

Go to **System and Maintenance** → **Maintenance** → **Log** .

Set the major and minor type of the log type. Set the start time and end time for searching, and click **Search**.

The results will be displayed below, which including the No., time, the major type the minor type, the channel No., the local/remote user information, the remote host IP, etc.

## 8.6.17 Certificate Management

It helps to manage the server/client certificates and CA certificate.



### Note

The function is only supported by certain device models.

---

## Create and Import HTTPS Certificate

### Steps

1. Go to **System and Maintenance** → **Safe** → **Certificate Management** .
2. In the **HTTPS Certificate** area, click **Create Certificate Request**.
3. Input certificate information and click **Save**.
  - Click **View** and the created certificate will be displayed.
  - The certificate will be saved automatically.
4. Download the certificate and save it to an asking file in the local computer.
5. Send the asking file to a certification authority for signature.
6. Import the signed certificate.
  - 1) In the **Import Key** area, select a certificate from the local, and click **Import**.
  - 2) In the **Import Communication Certificate** area, select a certificate from the local, and click **Import**.

## Create and Import SYSLOG Certificate

### Steps

1. Go to **System and Maintenance** → **Safe** → **Certificate Management** .
2. In the **SYSLOG Certificate** area, click **Create Certificate Request**.
3. Input certificate information and click **Save**.
  - Click **View** and the created certificate will be displayed.
  - The certificate will be saved automatically.
4. Download the certificate and save it to an asking file in the local computer.
5. Send the asking file to a certification authority for signature.
6. Import the signed certificate.
  - 1) In the **Import Key** area, select a certificate from the local, and click **Import**.
  - 2) In the **Import Communication Certificate** area, select a certificate from the local, and click **Import**.

## Import CA Certificate

### Before You Start

Prepare a CA certificate in advance.

### Steps

1. Go to **System and Maintenance** → **Safe** → **Certificate Management** .
2. Create an ID in the **CA Certificate ID** area.



The input certificate ID cannot be the same as the existing ones.

---

3. Upload a certificate file from the local.
4. Click **Import**.

## Chapter 9 Configure the Device via the Mobile Web

### 9.1 Login

You can login via mobile browser.

---

#### Note

Make sure the device is activated.


---

Enter the device IP address in the address bar of the mobile browser and tap **Enter** to enter the login page.

Enter the device user name and the password. Tap **Login**.

### 9.2 Overview


You can view the device status, conduct remote control, etc.



**Figure 9-1 Status and Quick Settings**


You can view the device status. If there is exception, you can tap to view the component details.

You can tap to fast enter the basic settings page and person page.



**Figure 9-2 Remote Control**

You can remotely control barrier by tap the icons.




**Figure 9-3 Network Status and Basic Information**


You can view network status, model, serial No. and firmware version, and you can tap to fast enter the basic information page.

## 9.3 Configuration

### 9.3.1 Turnstile Basic Parameters

You can set the basic parameters of the turnstile.

Tap **Basic Settings** of the shortcut entry on the overview page or tap  → **System Settings** → **Basic Information** .



**Figure 9-4 Turnstile Basic Parameters**

Tap **Regular Passing Settings** to set the entrance and exit's passing mode.

Tap **Lane Width Diagram** to view the device diagram.

Tap **Save**.

### **9.3.2 Person Management**

You can add, edit, delete, and search person via mobile Web browser.

#### **Steps**

1. Tap **User** of the shortcut entry or tap  → **Person Management** to enter the settings page.

The screenshot shows a mobile application interface for adding a person. At the top, there is a navigation bar with a back arrow on the left, the title 'Add Person' in the center, and a 'Save' button on the right. Below the navigation bar is a form with several fields:

- \*Employee ID**: A text input field with the placeholder text 'Please enter.'
- Name**: A text input field with the placeholder text 'Please enter.'
- Long-Term Effective User**: A toggle switch that is currently turned off.
- Start Date**: A date and time picker showing '2024-01-23 00:00:00' with a right-pointing arrow.
- End Date**: A date and time picker showing '2034-01-22 23:59:59' with a right-pointing arrow.
- User Role**: A dropdown menu showing 'Normal User' with a right-pointing arrow.
- Card**: A text input field with the placeholder text 'Not added.' and a right-pointing arrow.

**Figure 9-5 Add Person**

**2. Add person.**

- 1) Tap+.
- 2) Set the following parameters.

**Employee ID**

Enter the employee ID. The Employee ID cannot be 0 or exceed 32 characters. It can be a combination of uppercase, lowercase letters and numbers.

**Name**

Enter your name. The name supports numbers, uppercase and lowercase English, and characters. The name is recommended to be within 32 characters.

**Long-Term Effective User**

Set the user permission as long-term effective.

**Start Date/End Date**

Set **Start Date** and **End Date** of user permission.

### User Role

Select your user role.

### Card

Add card. Tap **+**. Enter the **Card No.**, and select the **Card Type**. Tap **Save** to add the card.

3) Tap **Save**.

3. Tap the user that needs to be edited in the user list to edit the information.

4. You can search the user by entering the employee ID in the search bar.

### 9.3.3 View Device Basic Information

You can view the device name, language, model, serial No., version, and Mac address, etc.

Tap  → **System Settings** → **Basic Information** .

You can change the device name.

You can view the device language, model, serial No., version, local RS-485 number, number of alarm input, number of alarm output, Mac address and factory information, etc.

Tap **Device Capacity** to view the quantity and capacity of person, card and event.

Tap **Save**.

### 9.3.4 Set Device Time

Set the time zone of the device and the device current time.

Tap  → **System Settings** → **Time Settings**.




Figure 9-6 Time Settings

**Time Zone**

Tap to select a time zone for the device.

**Time Sync. Mode**

**Manual**

By default, manually synchronization is checked, you can set the device time manually.

**NTP**

You should Set the NTP server's IP address, NTP port, and interval.

**Enable DST**

You can enable DST and set the start time and end time of DST. And also you can set the bias.  
Tap **Save**.

## 9.3.5 User Management

You can change user password.

Tap  → **User Management** on the home page.

Tap the user, enter the old password and create a new password, and confirm the password.

Tap **Save**.

## 9.3.6 Network

### Wired Network

Set wired network.

Tap  → **Network Settings** → **TCP/IP** to enter the configuration page.

#### NIC Type

Select a NIC type from the drop-down list.

#### DHCP

If you disable the function, you should set the IPv4 address, IPv4 subnet mask, IPv4 default gateway, IPv6 mode, IPv6 address, IPv6 subnet prefix length, IPv6 default gateway.

If you enable the function, the system will allocate the IPv4 address, IPv4 subnet mask, the IPv4 default gateway automatically.

#### MAC Address and MTU

You can view the default MAC address and MTU.

#### IPv6 Mode

##### Route Advertisement

The IPv6 address is generated by combining the route advertisement and the device Mac address.



#### Note

Route advertisement mode requires the support from the router that the device is connected to.

---

#### Manual

Enter **IPv6 Address**, **IPv6 Subnet Mask**, and **IPv6 Default Gateway**. Consult the network administrator for required information.

#### DHCP

The IPv6 address is assigned by the server, router, or gateway.

#### DNS Server

---

## Note

Only when DHCP is enabled can DNS server be set.

---

Set the preferred DNS server and the alternate DNS server according to your actual need.

## Set Port Parameters

You can set the HTTP, HTTPS according to actual needs when accessing the device via network.

Tap  → **Network Service** → **HTTP(S)** to enter the setting page.

### HTTP

It refers to the port through which the browser accesses the device. For example, when the HTTP Port is modified to 81, you need to enter **http://192.0.0.65:81** in the browser for login.

### HTTPS

Set the HTTPS for accessing the browser. Certificate is required when accessing.

## Platform Access

Platform access provides you an option to manage the devices via platform.

### Steps

1. Tap  → **Device Access** → **Hik-Connect** to enter the settings page.

---

## Note

Hik-Connect is an application for mobile devices. With the App, you can view live image of the device, receive alarm notification and so on.

---

2. Slide to enable the function.

3. You can enable **Custom** to enter the server address.

---

## Note

- 6 to 12 letters (a to z, A to Z) or numbers (0 to 9), case sensitive. You are recommended to use a combination of no less than 8 letters or numbers.
- 

4. You can view **Register Status** and **Binding Status**.

5. You can tap **Bind An Account** → **View QR Code** , scan the QR code to bind an account.

6. Tap **Save** to enable the settings.

## Set OTAP Protocol

You can access the device to the maintenance platform by OTAP protocol to realize searching and gaining device information, uploading device running status and exceptions, rebooting and upgrading.

## Steps

1. Tap  → Device Access → OTAP .




Figure 9-7 OTAP

2. Slide **Enable**.
3. Set server address, port, device ID and encryption key.
4. Tap **Test**, and make sure the device can connect to the server and registration completed.
5. Tap **Save**.


## Result

Refresh the web page or reboot the device to make sure the OTAP's **Register Status** turns to online.

## Set Network Penetration Service

When the device is deployed on the LAN, penetration service can be enabled to achieve remote device management.

## Steps

1. Tap  → **Device Access** → **Network Penetration Settings** to enter the configuration page.
2. Enable **Enable Penetration Service**.
3. Enter **Server IP Address** and **Server Port**.
4. Enter login **User** and **Password**.
5. Set **Heartbeat Timeout**. The range is 1 to 6000.
6. You can view **Online Status**. Click **Refresh** to view the latest status.
7. Tap **Save**.

## 9.3.7 Event Search

Tap  → **Event Search**.

Enter the search conditions, including the employee ID, the name, the card No., the start time, and the end time, and tap **Search**.



### Note

Support searching for names within 32 digits.


---

The result will display in the list.

## 9.3.8 Set Audio

Set the device volume.

### Steps


1. Tap  → **Audio** to enter the settings page.
2. You can adjust the device output volume according to your actual needs.
3. You can enable voice prompt according to your actual needs.


## 9.3.9 Access Control Settings

### Set Authentication Parameters

Set authentication parameters.

### Steps

1. Tap  → **Access Control** → **Authentication Settings** .



**Figure 9-8 Authentication Settings**

2. Tap **Save** after configuration.

**Terminal**

Choose **Entrance** or **Exit** for settings.

**Terminal Type/Model**

You can view the current terminal type and model.

**Enable Authentication Device**

The terminal can be used for card swiping normally when the function is enabled.

**Authentication**

Select an authentication mode according to your actual needs from the drop-down list.

### **Authentication Interval**

You can set the authentication interval of the same person when authenticating. The same person can only authenticate once in the configured interval. A second authentication will be failed. If other people authenticate in the configured interval, this person can authenticate again.

---

#### **Note**

The configuration range is 0 to 255 s.

---

### **Alarm of Max. Failed Attempts**

Enable to report alarm when the card reading attempts reach the set value.

---

#### **Note**

The configuration range is 1 to 10.

---


### **Communication with Controller Every**

When the access control device cannot connect with the card reader for longer than the set time, the card reader will turn offline automatically.

## **Set Door Parameters**

You can set door name, open duration and exit button parameters.

Tap  → **Access Control** → **Door Parameters** .



**Figure 9-9 Door Parameters**

Select entrance or exit for configuration, configure **Name** and **Open Duration**, and select **Exit Button Type**.


Configure **Door Remain Open Duration with First Person**. The mode is applicable for the passing of groups of persons, such as visitors entering the scenic spots. After the set person passes through, the door will open for a set time and other persons can pass through without authentication.

Click **Save** to save the settings after the configuration.

## Terminal Settings

Set the working mode.

Tap  → **Access Control** → **Terminal Parameters** to enter the settings page.



**Figure 9-10 Terminal Parameters**

### **Permission Free Mode**

The device will not verify the person's permission, but only the person's validity period. If the person is in the validity period, the barrier will open.

You can enable **Verify Credential Locally**. After enabling the function, the device will only verify the person's permission without the schedule template, etc.

### **Access Control Mode**

The device works normally and will verify the person's permission to open the barrier.

### **Remote Authentication**

The device will upload the person's authentication information to the platform. The platform will judge to open the barrier or not.


### **Verify Credential Locally**

The device will only verify the person's permission without the schedule template, etc.

## **Set Card Security**

Configure cards for the device.

Tap  → **Access Control** → **Card Security** .



**Figure 9-11 Card Security**

Configure card parameters, and click **Save**.

**Enable NFC Card**

In order to prevent the mobile phone from getting the data of the access control, you can disable NFC card to increase the security level of the data.

**Enable M1 Card**

Enable M1 card and authenticating by presenting M1 card is available.

## M1 Card Encryption

M1 card encryption can improve the security level of authentication.

### Sector

Enable the function and set the encryption sector.



#### Note

It is recommended to encrypt sector 13.

---

## Enable EM Card

Enable EM card and authenticating by presenting EM card is available.



#### Note

If the peripheral card reader supports presenting EM card, the function is also supported to enable/disable the EM card function

---

## Enable DESFire Card

The device can read the data from DESFire card when enabling the DESFire card function.

### DESFire Card Read Content

After enable the DESFire card content reading function, the device can read the DESFire card content.


## Enable FeliCa Card

The device can read the data from FeliCa card when enabling the FeliCa card function.

## 9.3.10 People Counting Settings

Set people counting.

### Steps

1. Tap  → **People Counting Settings** to enter the configuration page.
2. Enable **People Counting**, and the device will count passing person's number.
3. Enable **Device Offline People Counting**, and the device will count people numbers even if it is offline.
4. Enable **Passing Event Record**, and the device will upload each person's passing event.
5. Set **Person Statistics Type**.

#### Invalid

Disable people counting.

#### Passing Detection


The number of all passing people.

#### Authentication Number

The number of passing people verified through card swiping, face recognition, etc.

6. Set **Passing Direction** and you can set the passing direction of the device.
7. Tap **Clear** to clear all people counting information.
8. Tap **Save**.

### 9.3.11 Other Settings

Tap  → **Other Settings** to enter the configuration page.

Set the parameters and tap **Save**.

#### Alarm Output Duration

The alarm output duration ranges from 0 s to 3599 s. 0 indicates continuous output.

#### Light Board Brightness

Drag the block or enter the value to adjust the brightness. The larger the value, the brighter the light becomes.

#### Anti-Passback Rule

Set the anti-passback rule as **By Authentication Status** or **By Passing Status**.

##### By Authentication Status

The person should pass the authentication or the anti-passback will be failed.

##### By Passing Status

The person cannot pass the authentication and the anti-passback will be completed.

#### Memory Mode

Multiple cards presenting for multiple person passing is allowable when enabling the memory mode. When the passing person's number exceeds the card presenting number, or after the latest person passing with no other person passing within the door open duration, the door will close automatically.

By default, it is disabled.


#### Fire Input Type

In the normally open state, closing triggers fire protection. In the normally closed state, disconnection triggers fire protection.

### 9.3.12 Upgrade and Maintenance

Restart device, restore device parameters, and upgrade device version.

#### Restart Device

Tap  → **Restart** .

Tap **Restart** to restart the device.

## Upgrade

Tap  → **Upgrade** .

Tap **Upgrade** to upgrade the device.


---

### **Note**

Do not power off during the upgrading.

---

## Restore Parameters

Tap  → **Default** .

### Restore to Default Settings

Tap **Restore to Default Settings**, enter the admin password and click **OK**. The device will restore to the default settings, except for the device IP address and the user information.

### Restore to Factory Settings

Tap **Restore to Factory Settings**, enter the admin password and click **OK**. All parameters will be restored to the factory settings. You should activate the device before usage.

## Log Export

Tap  → **Log Export** .

Select the log type, and tap **Export** to download the maintenance log.

### 9.3.13 Log Out

Log out the configuration page.

Tap  → **Logout** , tap **OK**.

If you need to enter the configuration page, you need to enter the user name and password again.

### 9.3.14 Open Source Software Licenses

You can view the open source software licenses.

Tap  to enter the page.

Tap **Open Source Software Licenses**.

### 9.3.15 View User Document


View the user document.

---

 **Note**

Only when you enter the mobile web by IP address, can you view the user document. Login by hot spot does not support the function.

---

Tap  to enter the page.

Tap **View Online Document** to view the user manual.

## Chapter 10 Other Platforms to Configure

You can also configure the device via iVMS-4200 Client Software or HikCentral Access Control. For details, see the platforms' user manual.

### **iVMS-4200 Client Software**

Click/tap the link to view the client software's user manual.

<http://enpinfodata.hikvision.com/analysisQR/showQR/ca930247>

## Appendix A. Event and Alarm Type

Event	Alarm Type
Force Accessing	None
Climb over Arm	Visual and Audible
Passing Timeout	None
Arm Obstructed	None

## Appendix B. Error Code Description

The tripod turnstile will display the error code on the seven-segment display if error occurred. Refer to the table below to find the description of each number.

Error Reason	Code
Optional Board Offline (If the board is not installed, the error code of "49" will appear but the device functions normally)	49



See Far, Go Further