



FEDERAL SIGNAL
Public Safety Systems



ValorTM Lightbar

*Installation, Maintenance,
and Service Manual*

Contents

CHAPTER 1 Safety Messages	5
Safety Message to Installers and Service Personnel of Warning Light Equipment.....	5
Safety Message to Operators of Warning Light Equipment.....	8
CHAPTER 2 An Overview of the Valor Lightbar.....	9
LED Lights, Colors, and Flash Patterns	9
Modular Connector System	9
Controller Options	9
Dimensions	10
Light Specifications	10
Electrical and Temperature	10
CHAPTER 3 Preparing the Valor for Installation	11
Unpacking the Lightbar	11
Connecting the Valor for the Lightbar Test.....	11
Quick Testing the Valor with the Lightbar Test.....	13
Selecting Internal SignalMaster Control	13
Selecting External SignalMaster Control	14
Entering Program Mode	15
Exiting Program Mode	19
Additional Main Bar Tests and Configurations	19
CHAPTER 4 Wiring the Valor in the Vehicle	22
Planning the Electrical Installation.....	22
Connecting Power to the Lightbar	23
Installing the Serial Interface Module	24
Wiring the Serial Interface Module	25
Testing the Installation.....	32
CHAPTER 5 Maintaining and Servicing the Valor	33
Cleaning the Lightbar Lens	33
Removing and Reinstalling the Lightbar Lens	34
Replacing a PCB.....	35
Disconnecting/Connecting Power and CAT5 at the Lightbar.....	36
Troubleshooting the Lightbar	39
Replacement Parts	41
Getting Technical Support and Service	41
Returning a Product to Federal Signal.....	41

CHAPTER 6 Wiring Schematics 43

Tables

Table 3.1 SW-2 DIP switch settings in Serial Interface Module 15

Table 3.2 Control wires from the Serial Interface Module..... 16

Table 3.3 Switch settings for Intersection operation 18

Table 3.4 SignalMaster control wires and warning patterns (internal Serial Interface Module control) 21

Table 4.1 Cross reference for controller leads (external Serial Interface Module control)..... 28

Table 5.2 Replacement parts 41

Figures

Figure 3.1 Serial Interface Module connections for testing and reprogramming 12

Figure 3.2 Serial Interface Module with cover attached..... 13

Figure 3.3 DIP switch settings in Serial Interface Module 14

Figure 3.4 SignalMaster flash sequences (internal Serial Interface Module control)..... 21

Figure 4.1 Relay-isolating devices with large filter capacitors 25

Figure 4.2 Wiring block diagram 25

Figure 4.3 SignalMaster 331105 controller (external Serial Interface Module control) 28

Figure 4.4 SmartSiren SS2000SM Series controller (external Serial Interface Module control)..... 29

Figure 4.5 SignalMaster control functions wired to ground for external Serial Interface Module control 30

Figure 4.6 SignalMaster control functions wired to 12 Vdc for internal Serial Interface Module control.... 31

Figure 5.1 Locations of the barrel nuts in lens (numbers indicate tightening sequence)..... 34

Figure 5.2 Locations of ROC PCBs..... 35

Figure 5.3 Locations of watertight connectors..... 36

Figure 5.4 Secondary lock mechanism in the plug and receptacle 37

Figure 6.1 Typical connections with a SignalMaster controller (external control)..... 44

Figure 6.2 Typical connections with a SW400SS Switch Module (internal control) 45

Figure 6.3 Typical connections with a SmartSiren Model SS2000SM controller 46

Figure 6.4 Typical connections with a non-SignalMaster controller 47

Figure 6.5 Typical connections with a PA640 controller 48

CHAPTER 1

Safety Messages

For your safety, read and understand this manual thoroughly before installing, operating, and servicing the Valor lightbar. The safety messages presented in this chapter and throughout the manual are reminders to exercise extreme care at all times. To download copies of the manual, go to www.fedsig.com or call the Federal Signal Service Department at 1-800-433-9132, 7 a.m. to 5 p.m., Monday through Friday (CT).

Safety Message to Installers and Service Personnel of Warning Light Equipment

WARNING

People's lives depend on your proper installation and servicing of Federal Signal products. It is important to read and follow all instructions shipped with this product. In addition, listed below are some other important safety instructions and precautions you should follow:

Before Installation or Service

Qualifications

- To properly install or service this equipment, you must have a good understanding of automotive mechanical and electrical procedures and systems along with proficiency in the installation and service of safety warning equipment. Always refer to the vehicle service manuals when performing equipment installations on a vehicle.

Light Hazards

- To be an effective warning device, this product produces bright light that can be hazardous to your eyesight when viewed at a close range. Do not stare directly into this lighting product at a close range or permanent damage to your eyesight may occur.
- Do not install the light system in an area that would block, impair, or blind the driver's vision. Ensure that the light system is mounted in a position that is outside of the driver's field of vision, so the driver can safely operate the vehicle.
- Federal Signal power supplies and lightheads are designed to work together as a system. Combining lightheads and a power supply from different manufacturers may reduce the warning effectiveness of the lighting system and may damage the components. You should verify or test your combination to ensure the system works together and meets federal, state, and local standards or guidelines.

Electrical Hazards

- Strobe systems present a shock hazard because they use high voltage to operate. Do not handle strobe cables, the power supply, or bulbs or remove the lens while the equipment is connected. Strobe systems can also hold their charge even after they have been turned off. After disconnecting power to the unit, wait five minutes before handling any parts of the strobe system.
- A light system is a high current system. In order for the system to function properly, a separate negative (–) connection and positive (+) connection must be made. All negative connections should be connected to the negative battery terminal and a suitable fuse should be installed on the positive battery terminal connection as close to the battery as possible. Ensure that all wires and fuses are rated correctly to handle the device and system amperage requirements.
- Never attempt to install aftermarket equipment that connects to the vehicle wiring without reviewing a vehicle wiring diagram available from the vehicle manufacturer. Ensure that your installation will not affect vehicle operation or mandated safety functions or circuits. Always check the vehicle for proper operation after installation.
- The lighting system components, especially light bulbs, strobe tubes, LEDs, and the outer housing, get hot during operation. Be sure to disconnect power to the system and allow the system to cool down before handling any components of the system.
- Halogen light bulbs and strobe tubes are pressurized and if broken, can burst and result in flying glass. Always wear gloves and eye protection when handling these components.
- Do not mount a radio antenna within 18 inches (45.7 cm) of the lighting system. Placing the antenna too close to the lighting system could cause the lighting system to malfunction or be damaged by strong radio fields. Mounting the antenna too close to the lighting system may also cause the radio noise emitted from the lighting system to interfere with the reception of the radio transmitter and reduce radio reception.
- Do not attempt to wash any unsealed electrical device while it is connected to its power source.

During Installation and Service

- DO NOT get metal shavings inside the product. Metal shavings in the product can cause the system to fail. If drilling must be done near the unit, place an ESD-approved cover over the unit. Inspect the unit after mounting to be sure there are no shavings present in or near the unit.
- To avoid a battery explosion, always disconnect the negative battery cable first and reconnect it last. Avoid causing a spark when connecting near or to the battery. The gases produced by a battery can cause a battery explosion that could result in vehicle damage and serious injury.
- DO NOT connect this system to the vehicle battery until ALL other electrical connections are made, mounting of all components is complete, and you have verified that no shorts exist. If the wiring is shorted to the vehicle body or frame, high current conductors can cause hazardous sparks resulting in electrical fires or flying molten metal.
- DO NOT install equipment or route wiring (or the plug in cord) in the deployment path of an airbag.
- If a vehicle seat is temporarily removed, verify with the vehicle manufacturer if the seat needs to be recalibrated for proper airbag deployment.

- Before mounting any components, check the manual to be sure that the component you are installing is suitable for use in that area of the vehicle. Many components are not suitable for use in the engine compartment or other extreme environmental exposure areas.
- The service life of light bulbs and strobes tubes will be shortened if the glass portion is touched during installation. Use gloves when handling these components. If the glass portion has been touched, clean the glass carefully with isopropyl alcohol.
- When drilling into a vehicle structure, be sure that both sides of the surface are clear of anything that could be damaged. Remove all burrs from drilled holes. To prevent electrical shorts, grommet all drilled holes through which wiring passes. Also, ensure that the mounting screws do not cause electrical or mechanical damage to the vehicle.
- Refer to the manual packed with the lighting system for proper electrical connections, additional precautions, and information.
- Because vehicle roof construction and driving conditions vary, do not drive a vehicle with a magnetically mounted warning light installed. The light could fly off the vehicle causing injury or damage. Repair of damage incurred because of ignoring this warning shall be the sole responsibility of the user.
- To avoid denting the roof of the vehicle, place the lightbar mounting feet as close to the outer edge of the roof as possible.
- Roof damage can occur if the hook adjustment bolts are over-tightened. On Arjent and Vista lightbars tighten the hook-adjustment bolts 10 ft-lb to 11 ft-lb. On all other lightbars tighten the adjustment bolts 6 ft-lb to 7 ft-lb.
- Locate the light system controls so the VEHICLE and CONTROLS can be operated safely under all driving conditions.

After Installation or Service

- After installation, test the light system to ensure that it is operating properly.
- To ensure proper operation, test all vehicle functions, including horn operation, vehicle safety functions, and vehicle light systems. Ensure that the installation has not affected the vehicle operation or changed any vehicle safety function or circuit.
- Scratched or dull reflectors, mirrors, or lenses will reduce the effectiveness of the lighting system. Avoid heavy pressure and use of caustic or petroleum based products when cleaning the lighting system. Replace any optical components that may have been scratched or crazed during system installation.
- Do not attempt to activate or de-activate the light system control while driving in a hazardous situation.
- You should frequently inspect the light system to ensure that it is operating properly and that it is securely attached to the vehicle.
- After installation and testing are complete, provide a copy of these instructions to instructional staff and all operating personnel.
- File these instructions in a safe place and refer to them when maintaining and/or re-installing the product.

Failure to follow these precautions may result in property damage, serious injury, or death.

Safety Message to Operators of Warning Light Equipment

⚠ WARNING

People's lives depend on your safe use of our products. Listed below are some important safety instructions and precautions you should follow:

- Do not attempt to activate or de-activate the light system control while driving in a hazardous situation.
- Although your warning system is operating properly, it may not be completely effective. People may not see or heed your warning signal. You must recognize this fact and continue driving cautiously.
- Also, situations may occur which obstruct your warning signal when natural and man-made objects are between your vehicle and others, such as raising your hood or trunk lid. If these situations occur, be especially careful.
- All effective sirens and horns produce loud sounds that may cause, in certain situations, permanent hearing loss. You and your passengers should consider taking appropriate safety precautions, such as wearing hearing protection.
- In order to be an effective warning device, this product produces bright light that can be hazardous to your eyesight when viewed at a close range. Do not stare directly into this lighting product at a close range or permanent damage to your eyesight may occur.
- It is important that you fully understand how to safely operate this warning system before use.
- You should only operate your vehicle and its light/sound system in accordance with your department's Standard Operating Procedures.
- If a selected function does not perform properly or if any of the lamps remain illuminated when the control is off, disconnect the power connector from the control unit and contact the nearest service center.
- At the start of your shift, you should ensure that the entire warning light system and the siren system is securely attached and operating properly.
- Suction cup mounting is for temporary applications only. The unit should be removed from the window and stored securely when not in use. Temperature changes and sunlight can cause suction cups to lose holding power. Periodically check the unit to be sure the suction cups have a firm grip on the mounting surface. An improperly secured light could fall off of the vehicle causing injury and damage.
- Holding power of magnetic mounting systems is dependent upon surface finish, surface flatness, and thickness of the steel mounting surface. Therefore, to promote proper magnetic mounting:
 - ✓ Mounting surface and magnets must be kept clean, dry, and free of foreign particles that prevent good surface contact.
 - ✓ Ensure that mounting surface is flat.
 - ✓ A magnet mounting system should not be used on vehicles with vinyl tops.
 - ✓ To prevent sliding of light assembly on mounting surface, quick acceleration and hard stops should be avoided.

Failure to follow these precautions may result in property damage, serious injury, or death.

CHAPTER 2

An Overview of the Valor Lightbar

The Valor Lightbar is a single-level LED lightbar with ROC™ (Reliable On-Board Circuitry) and Solaris® LED technologies. ROC eliminates approximately 85 percent of potential failure points by incorporating a printed circuit board (PCB) in one assembly to substantially reduce the number of electrical connections. Solaris S2 LED modules use offset, complex reflector surfaces for accurate beam-shaping and the highest optical efficiency. The reflectors' overlapping, 360-degree lighting eliminates weak spots and provides off-axis warning around the lightbar. The lightbar is shaped to provide maximum intersection warning, the most dangerous situation in moving traffic.

LED Lights, Colors, and Flash Patterns

The lightbar's internal microprocessor supplies three priority operational modes and a library of 27 flash patterns. To increase the safety of officers, pedestrians, and motorists, the lightbar has standard front and rear cutoff, dimming, and intersection warning. Bright white LED takedown and alley lights that are horizontally adjustable are also available with the HotFoot™ configured option.

Multi-color heads are available with up to three different colored LEDs, eliminating the loss of primary warning colors in takedown, alley, and directional warning positions. Individual Valor lightheads can flash between red, blue, amber, or white.

Modular Connector System

The Valor Lightbar has a waterproof (IP67) external connector system for power and communication to allow removal of the lightbar from the vehicle without opening the lightbar or the vehicle hood. The Valor is protected against reversed polarity damage. The Valor Lightbar may be installed in any vehicle with a 12-volt negative ground electrical system.

Controller Options

Flash patterns are controlled through the lightbar's CAT5 communication cable. The cable connects to the Serial Interface Module (Part Number 8583446), the Federal Signal Six-Button Serial Controller (Part Number 8623133), the Three-Button Serial Controller (Part Number 8623141), or the SmartSiren Series Platinum System or the System control head only.

With the Serial Interface Module, the Valor Lightbar can be activated by Federal Signal lightbar controllers, SignalMaster directional-light controllers, or by individual low-current switch boxes.

Other advanced features of the Valor Lightbar include:

- ◆ A high degree of reliability through the use of advanced microprocessors and other integrated circuits.
- ◆ One piece seamless construction that eliminates leaking bulkhead gaskets.
- ◆ High output, long-life LEDs with no bulbs to change.

Dimensions

Model	Length	Height	Width	Weight*
VALR44	43.7 in (111.0 cm)	1.96 in (5.0 cm)	19.8 in (50.4 cm)	39.3 lb (17.8 kg)
VALR51	51.3 in (130.3 cm)	1.96 in (5.0 cm)	19.8 in (50.4 cm)	43.2 lb (19.6 kg)

*With standard mounting feet

Light Specifications

Lighting Option	Current Draw*	Lamp Technology	Reflector Style
LED (all heads)	1.0 A	High brightness LED	Offset, compound curve, polished reflector

*Amperage in Steady Burn Mode

Electrical and Temperature

Model	Electrical Potential	Current Draw*	Operating Temperature
VALR44	12.8 Vdc	12.0 A 14.0 A with HotFoot	-40 °F to 149 °F (-40 °C to 65 °C)
VALR51	12.8 Vdc	14.0 A 16.0 A with HotFoot	-40 °F to 149 °F (-40 °C to 65 °C)

*Amperage for a typically loaded lightbar with all lights flashing at 50 percent duty cycle

CHAPTER 3

Preparing the Valor for Installation

Taking the preparatory steps in this chapter before mounting and wiring the lightbar to a vehicle will help ensure that your installation is fast, easy, and error free. In addition to instructions for quick testing the lightbar, this chapter has instructions for changing default settings and flash patterns with the Serial Interface Module. The number of available flash patterns vary between the Serial Interface Module and the SmartSiren Platinum System. If you are using the SmartSiren Platinum System, refer to the “Smart Siren Platinum Installation, Maintenance, and Service Manual” (Doc. No. 2562502) and to the “Smart Siren Platinum Control Pad Configuration Software Manual” (Doc. No. 2562418) programming instructions.

Unpacking the Lightbar

Carefully unpack the lightbar assembly and any other products included in the shipment. Inspect them for damage that may have occurred during shipping. If a product has been damaged, do not install or operate it. Immediately file a claim with the carrier describing the damage. Carefully check all envelopes, shipping labels, and tags before removing or destroying them. If you are missing any parts, contact Customer Support at 1-800-264-3578, 7 a.m. to 5 p.m., Monday through Friday (CT).

Connecting the Valor for the Lightbar Test

⚠ WARNING

HEAVY OBJECT—Use lifting aids and proper lifting techniques when removing or replacing this product. Failure to follow this warning may cause personal injury.

NOTICE

REVERSE POLARITY / MISWIRING—Reverse polarity or incorrect voltage may damage the lightbar. To avoid damage to the lightbar, ensure that the battery voltage is the same as the voltage rating of the lightbar and that the lightbar’s red and black power lines are connected to the battery lugs in the correct polarity.

The Valor does not require any internal wiring. Two 10 AWG power conductors (red and black) and a CAT5 cable exit the lightbar. The lightbar’s basic light functions are communicated through the CAT5 cable, which connects to the Serial Interface Module, SmartSiren Platinum, or other Federal Signal controllers.


The electrical connections in this section enable you to perform a quick test of the lightbar with the Serial Interface Module. The Serial Interface Module communicates between an installer-supplied lightbar/siren controller, a SignalMaster controller, or a switch box and the lightbar. To minimize the number of discrete wires to the lightbar, control head functions are wired to the Module through a 3-foot-long, 24-conductor cable harness (Table 3.3 on page 19). The information is converted to a digital format and communicated through the CAT5 serial communication cable.

The numbers in the steps below refer to the wires in Figure 3.1. To connect the Valor to the battery and Serial Interface Module:

1. To supply power to the lightbar, use a fully-charged 12-volt automotive battery with terminal lugs.
2. Place the lightbar on a sturdy, flat surface.
3. Plug the CAT5 communication cable (1) from the lightbar into the Serial Interface Module (J1).
4. Plug the 24-pin harness (2) into the Serial Interface Module.
5. Attach the lightbar's black ground-power line (3) to the negative battery (-GND) lug.
6. Attach the lightbar's red power line (4) through a 40 A Maxi™ fuse to the positive battery (+BAT) lug.
7. Attach the white wire (5) from the 24-pin harness through a 1 A fuse to the positive battery (+BAT) lug.
8. Attach the black wire and the black/white wire (6) from the 24-pin harness to the negative battery (-GND) lug.

The lightbar is now ready for testing.

Figure 3.1 Serial Interface Module connections for testing and reprogramming



Quick Testing the Valor with the Lightbar Test

⚠ WARNING

LIGHT HAZARDS—*To be an effective warning device, this product produces bright light that can be hazardous to your eyesight when viewed at a close range. Do not stare directly into this lighting product at a close range or permanent damage to your eyesight may occur.*

IMPORTANT: Ensure that SW-2 Switch 3 is in the up position for the Lightbar Test. The down position is ON for the Scene Light, Right option in lightbars with Spectralux Technology (Valor and Vision SLR). For the scene light control wires see Figure 4.5 on page 30 and Figure 4.6 on page 31.

The Lightbar Test does not test the optional Steady Burn LEDs. To test and configure these LEDs, see “Testing the Steady Burn LEDs (HotFoot Only)” on page 19.

Before programming and testing flash patterns, perform the Lightbar Test to ensure that all LEDs light properly by following these steps:


1. Apply 12 Vdc (+BAT) to the Lightbar Test control wire (black/white/red) from the Serial Interface Module.
2. The LEDs flash from red to blue to white/amber.
3. Remove 12 Vdc from the Lightbar Test control wire.

Selecting Internal SignalMaster Control

The Interface Module SignalMaster control leads are defined in Table 3.2 on page 16. The SignalMaster can be configured for internal operation. Power (+BAT) applied to the specified control lead activates the lightbar’s internal SignalMaster controller. The Internal SignalMaster setting controls the flash pattern, rather than driving each SignalMaster head.

1. Unplug the 24-pin harness from the Serial Interface Module.
2. Use a 1/4-inch driver to remove the four 8-32 x 1/4 hex-head screws on the Serial Interface Module and remove the cover (Figure 3.2).

Figure 3.2 Serial Interface Module with cover attached



3. On the Interface Module PCB, move JP 1 from EXT to INT (Figure 3.3 on page 14).


4. Reinstall the cover on the Interface Module.
5. Move Switch 4 on SW-2 to the down position (ON).
6. Plug the 24-pin harness into the Serial Interface Module.

Selecting External SignalMaster Control

The Interface Module comes factory preset for the external SignalMaster option. The Interface Module drives each SignalMaster head independently via an external Federal Signal SignalMaster controller or the SS2000SM Series Siren. Either device will provide an independent ground signal to illuminate each head.

1. Unplug the 24-pin harness from the Serial Interface Module.
2. On the Serial Interface Module, use a 1/4-inch driver to remove the four 8-32 x 1/4" hex-head screws and remove the cover.
3. On the Serial Interface Module PCB, move JP 1 from INT to EXT (Figure 3.3).
4. Reinstall the cover on the Interface Module.
5. Move Switch 4 on SW-2 to the up position (OFF) (Table 3.1 on page 15).
6. Plug the 24-pin harness into the Serial Interface Module.

Figure 3.3 DIP switch settings in Serial Interface Module



290A6561

Entering Program Mode

To switch the module from Operation Mode to Program Mode:

1. Unplug the 24-pin harness from the Serial Interface Module.
2. On the Serial Interface Module, move Switch 6 on SW-2 to the down position (ON) (Figure 3.3 on page 14).
3. Plug the 24-pin harness into the Serial Interface Module.

SW-2 DIP Switch Settings in the Serial Interface Module

For the location of SW-2, see Figure 3.3 on page 14. Table 3.1 lists the DIP switch settings in the Serial Interface Module for programming flash patterns.

Selecting a Flash Pattern

When you press and release the SW-1 pushbutton on the Serial Interface Module to select a pattern, the lightbar briefly turns off and then displays the next pattern. To cycle backwards to a previous pattern, move Switch 5 to up position (ON) on SW-2.

Table 3.1 SW-2 DIP switch settings in Serial Interface Module

SW-2 Switch Number	Switch Setting		Function
	Up (OFF)	Down (ON)	
1	✓		Front/Rear LEDs cut off (turn off) when 12 Vdc is applied their control wires (Table 3.2 on page 16)
1		✓	Front/Rear LEDs enable (turn on) when 12 Vdc is applied to their control wires
2	✓		Keep in OFF position.
3	✓		Intersection when 12 Vdc is applied to blue/black wire. Lightbar Test when 12 Vdc is applied to black/white/red wire.
		✓	Left scene light turns on when 12 Vdc is applied to blue/black wire. Right scene light turns on when 12 Vdc is applied to black/white/red wire. Intersection and Lightbar Test are unavailable. This function applies only to lightbars with Spectralux technology (Valor and Vision SLR).
4	✓		SignalMaster, External controller
4		✓	SignalMaster, Internal controller
5	✓		Cycle forward through the selection of flash patterns
5		✓	Cycle backward through the selection of flash patterns
6	✓		Operation Mode
6		✓	Program Mode
7			Switch for Intersection operational settings (Table 3.3 on page 18)
8			Switch for Intersection operational settings (Table 3.3)

Programming Priority Modes 1, 2, 3, and Intersection

The three modes operate with Mode 3 having the highest priority: Mode 3 overrides Mode 2, and Mode 2 overrides Mode 1. When the lightbar operates in one of these modes, the SignalMaster modules keep sequence with the flash pattern.

You can change default Mode flash patterns by programming each mode with one of patterns in the lightbar’s library. A typical setup would be:

- **Mode 1:** Rear LEDs
- **Mode 2:** Front/Rear LEDs
- **Mode 3:** Siren (SmartSiren® or Federal Signal compatible), and Front/Rear LEDs and Flash Takedown/Alley LEDs on the main bar
- **Modes 1 and 2:** Front/Rear Cutoff

NOTE: If the lightbar needs to be programmed after you connect a progressive slide switch, the programming sequence must be Mode 3, Mode 2, Mode 1, Intersection.

Table 3.2 Control wires from the Serial Interface Module

Lightbar Controls	Wire Color	Description
Mode 1	Blue	Lowest priority
Mode 2	Blue/White	Overrides Mode 1.
Mode 3	Black/Red	Overrides Modes 1 and 2.
Steady Burn (HotFoot only)	Red/White	One or more LEDs steadily burn when 12 Vdc is applied to the control wire for a Mode and the control wire for Steady Burn.
Front Cutoff	Green/White	Turns off the front of the lightbar.
Front Enable		Turns on the front of the lightbar.
Rear Cutoff	Orange/Black	Turns off the rear of the lightbar.
Rear Enable		Turns on the rear of the lightbar.
Low Power	White/Black/Red	Dims the lights approximately 50 percent to prevent blinding approaching drivers. Low Power is only available in Modes 1 and 2 and is disabled when switched to another flash pattern, including Mode 3 and Intersection.
Flash Takedown/Alley	Red/Black	Flashes the alley and takedown lights in Modes 1, 2, or 3.
Left Alley	Green/Black	Turns on left alley lights. Overrides the Flash Takedown/Alley lights.
Right Alley	Orange/Red	Turns on right alley lights. Overrides the Flash Takedown/Alley lights.
Takedown	White/Black	Provides white light to the front. Overrides Flash Takedown/Alley lights and front cutoff.

continued on next page

Table 3.2 Control wires from the Serial Interface Module (*continued*)

Lightbar Controls	Wire Color	Description
Intersection (SW-2 Switch 3 in the up position)	Blue/Black	Dims the lights approximately 50 percent to prevent blinding approaching drivers. Low Power is only available in Modes 1 and 2 and is disabled when switched to another flash pattern, including Mode 3 and Intersection. Scene Light, Left is unavailable.
Scene Light, Left (SW-2 Switch 3 in the down position)		Applying 12 Vdc to the Scene Light, Left wire turns on the left half of the lightbar (only for Valor and Vision SLR). Intersection is unavailable.
Lightbar Test Pattern (SW-2 Switch 3 in the up position)	Black/White/Red	Flashes the LEDs sequentially and then flashes the takedown and alley lights. Scene Light, Right is unavailable.
Scene Light, Right (SW-2 Switch 3 in the down position)		Applying 12 Vdc to the Scene Light, Right wire turns on right half of the lightbar. Lightbar Test Pattern is unavailable.

Mode 3

1. Apply 12 Vdc (+BAT) to the Mode 3 control wire (black/red) from the Serial Interface Module to display the assigned pattern.
2. On the Serial Interface Module, press and release the SW-1 pushbutton until the pattern you want appears on the lightbar.
3. Remove 12 Vdc from the Mode 3 control wire.

Mode 2

1. Apply 12 Vdc (+BAT) to the Mode 2 control wire (blue/white) from the Serial Interface Module to display the assigned pattern.
2. On the Serial Interface Module, press and release the SW-1 pushbutton until the pattern you want appears on the lightbar.
3. Remove 12 Vdc from the Mode 2 control wire.

Mode 1

1. Apply 12 Vdc (+BAT) to the Mode 1 control wire (blue) from the Serial Interface Module to display the assigned pattern.
2. On the Serial Interface Module, press and release the SW-1 pushbutton until the pattern you want appears on the lightbar.
3. Remove 12 Vdc from the Mode 1 control wire.

Intersection

The Intersection flash pattern overrides all three priority modes when activated. To select a new pattern, you must apply 12 Vdc to the control wire for either Mode 1, 2, or 3 (Table 3.2 on page 18) and the blue/black control wire for Intersection. (SW-2 Switch 3 in the Serial Interface Module must be in the up position for this function. See Table 3.2 on page 17.)

NOTE: With the flexibility of the SmartSiren Platinum System, both the Intersection and the Scene Light, Left option are available in Vision SLR and Valor lightbars without the need to choose one or the other.

NOTE: This procedure only programs the Intersection pattern. It does not assign the pattern to a Mode.

1. Apply 12 Vdc (+BAT) to a control wire for either Mode 1, 2, or 3, and the control wire for Intersection from the Serial Interface Module.
2. On the Serial Interface Module, press and release the SW-1 pushbutton until the pattern you want appears on the lightbar.
3. Remove 12 Vdc from the Mode and Intersection control wires.

Intersection Operational Settings

Select one of three options to turn on the Intersection pattern:

- HIGH with +BAT power maintained (default): the lightbar displays the Intersection pattern until power is removed.
- TAP II (push-on/push-off): The Intersection flash pattern is turned on and off by pressing a momentary contact switch, such as a horn button. Momentary 12 Vdc turns on the pattern, a second momentary 12 Vdc signal turns it off.
- 8-Second Timeout activated by +BAT: momentary 12 Vdc turns on the Intersection flash pattern for eight seconds.

To change from High to Tap II or 8-Second Timeout.

1. Unplug the 24-pin harness from the Serial Interface Module.
2. On the Serial Interface Module, set Switch 7 and Switch 8 on SW-2 to select a method of operation (Figure 3.3 on page 14 and Table 3.3). Each setting is independent of the other.
3. Plug the 24-pin harness into the Serial Interface Module.

Table 3.3 Switch settings for Intersection operation

Operational Settings	SW-2	
	SW7	SW8
High (+BAT maintained)	OFF (up)	OFF (up)
Tap II (+BAT, push on/push off)	ON (down)	OFF (up)
8-Second Timeout (activated by +BAT)	OFF (up)	ON (down)

Front/Rear Cutoff or Enable

The operational setting for Front/Rear Cutoff or Enable must be programmed after Mode and Intersection. The default setting is for Cutoff in which the Front or Rear LEDs turn off when 12 Vdc (+BAT) is applied to their control wires. In contrast, Enable turns on these LED modules when +BAT is applied to their control wires. Both the front and rear LEDs share the same operational setting and are not independent.

To program this feature:

1. Unplug the 24-pin harness from the Serial Interface Module.
2. On the Serial Interface Module, move Switch 1 on SW-2 to:
 - a) the down (on) position for Front/Rear Enable.
 - b) the up (off) position for Front/Rear Cutoff.
3. Plug the 24-pin harness into the Serial Interface Module.

NOTE: When set to Enable, 12 Vdc must be applied to a Mode control wire and the Front and/or Rear Enable control wire for the lightbar to operate.

In a typical installation, if you want only the Rear LED modules to flash in Mode 1, set the operation for Enable. Connect the green/white and blue/white control wires to the Mode 2 connection and the orange/black and blue control wires to the Mode 1 connection.

Exiting Program Mode

When you are finished programming patterns, switch the Serial Interface Module from Operation Mode to Program Mode.

1. Unplug the 24-pin harness from the Serial Interface Module.
2. On the Serial Interface Module, move SW-2 Switch 6 to the up (OFF) position.
3. Plug the 24-pin harness into the Serial Interface Module.

Additional Main Bar Tests and Configurations

After programming and testing the Modes 1, 2, and 3 and the Intersection flash pattern, test the Steady Burn LEDs and Flash Takedown/Alley lights to ensure they function properly. The test procedures are described in the next sections.

Testing the Steady Burn LEDs (HotFoot Only)

The Steady Burn LEDs are factory configured per the customer order for one of these options:

- No Steady Burn (the LEDs flash with the pattern)
- Driver's side Steady Burn
- Driver's and passenger's side Steady Burn

1. Apply 12 Vdc (+BAT) to the red/white control wire for the Steady Burn LEDs and a control wire for Mode 1, 2, or 3 (Table 3.2 on page 16). The LEDs light and stay on (default setting).
2. Remove 12 Vdc from the Mode and Steady Burn control wires.

Testing the Flash Takedown/Alley Lights

1. Apply 12 Vdc (+BAT) to the control wire for Mode 1, 2, or 3 (Table 3.2 on page 16).
2. Apply 12 Vdc (+BAT) to the red/black control wire for the Flash Takedown/Alley lights to flash the them.
3. Remove 12 Vdc from the Mode and Flash Takedown/Alley control wires.

Testing the Left and Right Alley Lights

1. Apply 12 Vdc (+BAT) to the control wire for either the left or right alley LED (Table 3.2 on page 16) to turn it on.
2. Remove 12 Vdc from the control wire.
3. Repeat steps 1 and 2 for the other alley light.

Testing the Takedown Lights

Apply 12 Vdc (+BAT) to the white/black control wire to turn on the takedown lights.

Testing the Left and Right Scene Lights

This function applies only to lightbars with Spectralux Technology (Valor and Vision SLR). Place SW-2 Switch 3 in the Serial Interface Module in the down position (ON) to activate this option, then cycle power to the lightbar. (Intersection and the Lightbar Test are unavailable.)

Applying 12 Vdc to the Scene Light, Left wire (white/black/red) turns on the left half of the lightbar. Applying 12 Vdc to the Scene Light, Right wire (black/right/red) turns on right half of the lightbar.

Testing the Low Power Function

The Low Power function dims the main bar LEDs approximately 50 percent to prevent blinding approaching drivers.

NOTE: The Low Power function only operates in Mode 1 or Mode 2. It is disabled when the lightbar is turned off or switched to another flash pattern, including Mode 3 or Intersection.

⚠ WARNING

Enabling the Low Power Mode in the lightbar causes the light output of the lightbar to fall below current light output standards and guidelines for emergency warning lights. Use extreme caution when using this mode. Ensure that the ambient light conditions are low enough that you are seen and that the reduction of glare from the lightbar is safer than full light output in the situation. Failure to heed this warning may result in serious injury or death to you or others in your vicinity.

To dim the LEDs:

1. Apply 12 Vdc (+BAT) to the control wire for Mode 1 or 2 (Table 3.2 on page 16.)
2. Apply 12 Vdc (+BAT) to the white/black/red control wire for the Low Power function.
3. Remove 12 Vdc from the Mode and Low Power control wires.

To apply Low Power again after you program a flash pattern, disconnect 12 Vdc (+BAT) from the Low Power control wire and reapply it.

Testing the SignalMaster LEDs Modules for External Operation

If the Serial Interface Module is set to External SignalMaster operation (default), test the LED modules by applying ground (–GND) to the control wires listed in Table 3.4 on page 21.


Testing the SignalMaster LED Modules for Internal Operation

If the Serial Interface Module is set to Internal SignalMaster operation, test the LED modules by applying 12 Vdc (+BAT) to the control wires listed in Table 3.4 on page 21.

Table 3.4 SignalMaster control wires and warning patterns (internal Serial Interface Module control)

Warning Pattern	Control Wires	Description
LEFT	Red	Rear LEDs flash from right to left
CENTER	Green	Rear LEDs flash from center out to both sides
RIGHT	Green/Black/White	Rear LEDs flash from left to right
WARN 1	Orange/Green	Outer LEDs alternate
WARN 2	Orange	Two outer LEDs alternate
WARN 3	Blue/Red	Right four LEDs alternate with left four LEDs
WARN 4	Red/Green	Two outer LEDs flash, then the four LEDs between the inner and outer LEDs flash
FAST	White/Red	Operates the selected pattern 50 percent faster

Figure 3.4 SignalMaster flash sequences (internal Serial Interface Module control)



CHAPTER 4

Wiring the Valor in the Vehicle

Before proceeding, ensure that the lightbar has been installed on the vehicle roof in accordance with the instructions included with the mounting kit. Depending on the type of vehicle and mounting system feature, there are two options available for installing the lightbar to the roof of the vehicle: hook-on mounting or permanent mounting.

⚠ WARNING

INSTALLATION PRECAUTIONS—*The warning system and/or two-way radio system may operate improperly if a two-way radio antenna installed on or within 18 inches of the lightbar. Before permanently installing the lightbar or a two-way radio antenna, test the warning system and two-way radio system. DO NOT install a two-way radio antenna on the lightbar. Some installations may require the relocation of the two-way radio antenna to a trunk or fender location. DO NOT drill holes in the lightbar or install auxiliary devices on the lightbar or the warning system may fail.*

Planning the Electrical Installation

The lightbar is completely wired at the factory and does not require any additional internal wiring. All the conductors necessary for control of any and all basic and optional functions are contained in the CAT5 cable. The basic light functions of the Valor must be controlled by a installer-supplied control head.

To prevent damage to the lightbar and vehicle and ensure that all equipment operates properly, carefully plan where to mount and wire the lightbar and controlling equipment:

1. Verify that the lightbar and mounting hardware fit the vehicle.
2. Determine where to mount the lightbar on the vehicle.

⚠ WARNING

LOCATING OPERATOR CONTROLS—*The controls for the light system must be located so that the VEHICLE and CONTROLS can be operated safely under all driving conditions.*

⚠ WARNING

UNIT REQUIRES SHELTER FROM WEATHER—*The Serial Interface Module is NOT waterproof. It must be mounted in a location that is sheltered from rain, snow, standing water, etc.*

3. Determine where to mount the controlling equipment:
 - a) Trunk or remote location
 - b) Console

⚠ WARNING

AIRBAG DEPLOYMENT—Do not install equipment or route wiring in the deployment path of an airbag. Failure to observe this warning will reduce the effectiveness of the airbag or potentially dislodge the equipment, causing serious injury or death.

4. Decide where to route wiring around airbag areas.

⚠ WARNING

BATTERY EXPLOSION—To avoid a battery explosion, always disconnect the negative battery cable first and reconnect it last. Avoid causing a spark when connecting near or to the battery. The gases produced by a battery can cause a battery explosion that could result in vehicle damage and serious injury

5. Decide where to route the lightbar's power and ground wires.

⚠ WARNING

SEAT REMOVAL PRECAUTION—If a vehicle seat is temporarily removed, verify with the vehicle manufacturer if the seat needs to be recalibrated for proper airbag deployment. Failure to follow this warning cause serious injury or death.

6. To make wiring easier, remove the seats, spare tire, and pull down the headliner where needed.
8. Separate all electronic equipment wiring from two-way radio equipment wiring.
7. To avoid interference, keep two-way radio antennas a minimum of 18 in (45.7 cm) away from warning equipment.
8. Whenever possible, run full wire lengths. DO NOT splice the wires.
9. Do not coil excess wire. Leave a drain loop for servicing.
10. After drilling holes for wires, deburr them, smooth sharp edges, and insert grommets to protect the wires from chafing.
11. When you frame-ground the equipment, use the manufacturer-supplied ground locations in the vehicle.

IMPORTANT: After the installation, frequently inspect the lightbar and mounting feet to ensure that all fasteners and brackets are tight.

Connecting Power to the Lightbar

NOTE: Plan the location of the wire-routing hole in the vehicle roof so that the power and communication cables do not have tight bends and have some slack to allow disconnection on removal.

⚠ WARNING

BATTERY EXPLOSION—To avoid a battery explosion, always disconnect the negative cable first and reconnect it last. Avoid causing a spark when connecting near or to the battery. The gases produced by a battery can cause an electrical explosion that could result in vehicle damage and serious injury.

⚠ WARNING

REVERSE POLARITY / MISWIRING—Reverse polarity or incorrect voltage may damage the light. To avoid damage to the light, ensure that the battery voltage is the same as the voltage rating of the light and that the correct polarity is observed. If you are connecting to a cigarette lighter plug or 12 V outlet, connect the positive wire to the center terminal and connect the negative wire to the outer terminal.

1. Ensure that the lines are adequately fused as shown in the wiring schematics in Chapter 6 on page 41.
2. From the lightbar, route the CAT5 control cable into the vehicle cab or trunk near the eventual location of the Serial Interface Module. An input cable is also provided with the Interface Module.
3. Route and connect the black lead from the lightbar to the vehicle battery's ground (–GND) terminal.
4. Route and connect the red lead from the lightbar through the supplied 40 A Maxi fuse holder at the source, which is the positive battery terminal (+BAT).

Installing the Serial Interface Module

⚠ WARNING

UNIT REQUIRES VENTILATION—*The Serial Interface Module needs to radiate heat. Do not install it in an area where it cannot dissipate heat into the air. Do not mount it near a heater duct.*

⚠ WARNING

UNIT REQUIRES SHELTER FROM WEATHER—*The Serial Interface Module is NOT waterproof. It must be mounted in a location that is sheltered from rain, snow, standing water, etc.*

IMPORTANT: The Serial Interface Module must be installed within 36 in (91 cm) of the lightbar controller.

To mount the Serial Interface Module and make the power connections:

1. Use the Serial Interface Module as a template and scribe four drill-position marks at the selected mounting location. Mounting centers are 2.00 in x 5.95 in (5.08 cm x 15.11 cm).

⚠ WARNING

DO NOT DRILL INTO SERIAL INTERFACE MODULE—*DO NOT drill holes into ANY part of the Serial Interface Module. Damage to the unit, serious injury, or death may result.*

⚠ WARNING

DRILLING PRECAUTIONS—*Before drilling holes, check the area into which you plan to drill to ensure you do not damage vehicle components. All drilled holes should be de-burred and all sharp edges should be smoothed. All wires going through drilled holes should be protected by a grommet or convolute/split-loom tubing.*


2. Drill four mounting holes at the drill-position marks, sized for the recommended user-supplied #8 mounting hardware.
3. Secure the Serial Interface Module to the mounting surface with installer-supplied #8 hardware.
4. Install the CAT5 serial cable from the lightbar to the J3 output jack of the Serial Interface Module.
5. Install the three-foot-long, 24-conductor cable from the lightbar to the J1 input connector of the Serial Interface Module.

NOTE: Powering multiple devices with a common control wire may cause one or more devices to briefly remain functional after signal power is removed. For example, due to the high input filter capacitance, a strobe supply can briefly supply the current required to signal a lightbar function to remain on. If necessary, use a relay to isolate devices with large filter capacitors (Figure 4.1 on page 25). All components/wires are user-supplied.

⚠ WARNING

SHOCK HAZARD—Strobe and HID light systems generate high voltages. Disconnect power from the system and wait at least 5 minutes before opening the unit. Do not apply power to the unit while the unit is open. Failure to follow this warning could result in serious injury or death.

Figure 4.1 Relay-isolating devices with large filter capacitors



290A6562

*FUSE AMPERAGE DEPENDS ON AMPERAGE OF DEVICES

Wiring the Serial Interface Module

NOTICE


FUSE ELECTRICAL SOURCES—Always fuse current/voltage sources with a fuse connected near the power source. Be sure that the fuse is properly rated to protect the electrical load, the wiring and the connectors used in the circuit. Failure to follow this notice could result in vehicle or equipment damage.

This section is an overview of default settings that are activated when connecting LED and Mode control wires to 12 Vdc (+BAT). The basic light functions of the lightbar must be controlled by an installer-supplied control head. All programming and changes to default settings should be done after quick testing the lightbar and before installation. Programming is covered in “Programming Priority Modes 1, 2, 3, and Intersection” on page 16.

For a description of the control wires from the Serial Interface Module, see Table 3.3 on page 18. For typical installations with common controllers and switch boxes, see the wiring schematics in the Chapter 6 on page 43.

For wiring the controller’s functions to the Serial Interface Module’s 24-pin cable harness, see Table 4.1 on page 28 and the figures on pages 28 though 31. If additional wire is necessary for the harness (except ground), 22 AWG wire is adequate. The ground wires must be extended with 16 AWG or thicker wire.

Figure 4.2 Wiring block diagram



290A6563

Priority Modes 1, 2, and 3

To activate a priority mode, apply 12 Vdc (+BAT) to a mode control wire. Mode 3 (black/red) overrides Mode 2 (blue/white), and Mode 2 overrides Mode 1 (blue). You can program one of the flash patterns in the lightbar to each Mode input.

Steady Burn (HotFoot Only)

When the lightbar is equipped with one or more Steady Burn LED modules, applying 12 Vdc (+BAT) to the control wire (red/white) for Steady Burn turns on the LEDs when any Mode input is selected.

Front Cutoff

When 12 Vdc (+BAT) is applied to the Front Cutoff control wire (green/white), the selected Mode operation is deactivated to the front of the lightbar. Only the rear LEDs function. Additionally, with Flash Takedown/Alley (red/black) active, only the alley lights turn on.

Rear Cut-Off

When 12 Vdc (+BAT) is applied to the Rear Cutoff control wire (orange/black), the selected Mode operation is deactivated to the rear of the lightbar. Only the front LEDs flash.

NOTE: The operational settings for Front Cutoff and Rear Cutoff are not independent. The default setting is for 12 Vdc (+BAT) to be applied for the lightbar's front and rear lighthoods to turn them off (Cutoff). To change the default setting to turn on these LEDs when 12 Vdc is applied (Enable), see "Front/Rear Cutoff or Enable" on page 19.

Intersection

When 12 Vdc (+BAT) is applied to the Intersection control wire (blue/black) and a Mode control wire, it turns on the Intersection pattern. When 12 Vdc is removed, the lightbar returns to its previous state. SW-2 Switch 3 must be in the up (ON) position in the Serial Interface Module. (See Scene Light, Left, Right on page 27.)

NOTE: With the flexibility of the SmartSiren Platinum System, both the Intersection and the Scene Light, Left option are available in Vision SLR and Valor lightbars without the need to choose one or the other.

Flash Takedown/Alley

When 12 Vdc (+BAT) is applied to the Flash Takedown/Alley control wire (red/black) and a MODE control wire, the takedown and alley lights flash.

Left and Right Alley Lights

When 12 Vdc (+BAT) is applied to the Left (green/black) or Right Alley control wire (orange/red), the appropriate alley LEDs turn on. The left and right alley lights override the flash/takedown alley lights.

Takedown Lights

When 12 Vdc (+BAT) is applied to the Takedown control wire (white/black), the takedown LEDs turn on. Takedown overrides Flash Takedown/Alley and Front Cutoff.

Scene Light, Left and Scene Light, Right

This function applies only to lightbars with Spectralux Technology (Valor and Vision SLR). To use this function with the Serial Interface Module, place SW-2 Switch 3 in the Module in the down position (ON). When 12 Vdc is applied to the Scene Light, Left control wire (blue/black), the left half of the lightbar lights up. When 12 Vdc is applied to the Scene Light, Right wire (black/white/red), the right half of the lightbar lights up. Intersection and Lightbar Test are unavailable with these options.

Low Power

NOTE: Low power mode is disabled when the lightbar is in MODE 3 or displaying the Intersection flash pattern.

⚠ WARNING

USE LOW POWER FUNCTION PROPERLY—Enabling the Low Power function in the lightbar will cause the light output to fall below current light output standards and guidelines for emergency warning lights. Use extreme caution when using this function. Ensure that the ambient light conditions are low enough that you are seen and that the reduction of glare from the lightbar is safer than full light output in the situation. Failure to heed this warning may result in serious injury or death to you or others in your vicinity.

When 12 Vdc (+BAT) is applied to the Low Power control wire, the LEDs are dimmed to approximately 50 percent of their full brightness. Low Power is only functional in MODE 1 or MODE 2. Low Power is disabled when switching to another flash pattern, including Intersection. To use Low Power again, disconnect 12 Vdc from the Low Power control wire and reapply 12 Vdc to the Low Power control wire after a change in flash pattern occurs.

Ignition

Connect the white wire from the supplied J1 cable harness on the Interface Module to a 1 A fuse. Connect the fuse end as close as possible to switched ignition power. Power should also be present in the cranking position.

Connect the black and black/white wire from the 24-pin cable harness on J1 from the Serial Interface Module to battery ground (–GND). Use 16 AWG wire to extend the cable length.

SignalMaster Connections

If SignalMaster operation is not activated by a control head or external controller, the SignalMaster LED heads flash with the selected priority mode (Mode 1, 2, or 3) of operation.

External SignalMaster

The Serial Interface Module is preset for the External SignalMaster option. External operation uses the Serial Interface Module to drive each SignalMaster directional warning head independently through an external Federal Signal SignalMaster controller or SS2000SM series siren (Figure 4.3 on page 28 and Figure 4.4 on page 29). Either device provides an independent ground signal to turn on each head. To cross reference external SignalMaster wiring to a Federal Signal controller or the SM2000SM series siren, see Table 4.1 on page 28.

Internal SignalMaster

Internal operation uses the lightbar’s built-in SignalMaster controller to generate directional warning patterns. With internal operation, an external SignalMaster controller is not needed. A standard low-current switch box can activate the lightbar’s internal SignalMaster controller. For the jumper setting in the Serial Interface Module, see “Selecting Internal SignalMaster Control” on page 13. To activate the lightbar’s internal SignalMaster controller, apply 12 Vdc (+BAT) to the SignalMaster control wires.

Table 4.1 Cross reference for controller leads (external Serial Interface Module control)

24-Pin Harness from the Serial Interface Module	SIGNALMASTER* Wire (Figure 4.3)	SS2000SM* Wire (Figure 4.4)
Red	White	White (1)
Green	Brown	Brown (2)
Green/Black/White	Green	Green (3)
Orange/Green	Orange	Orange (4)
Orange	Purple	Purple (5)
Blue/Red	Gray	Gray (6)
Red/Green	Yellow	Yellow (7)
White/Red	Blue	Blue (8)

*Wire colors as described in the controller’s installation instructions.

Figure 4.3 SignalMaster 331105 controller (external Serial Interface Module control)




Figure 4.4 SmartSiren SS2000SM Series controller (external Serial Interface Module control)






Figure 4.5 SignalMaster control functions wired to ground for external Serial Interface Module control



* IGNITION POWER INCLUDES POWER IN THE CRANKING POSITION

Figure 4.6 SignalMaster control functions wired to 12 Vdc for internal Serial Interface Module control



* IGNITION POWER INCLUDES POWER IN THE CRANKING POSITION

290A5981D

Testing the Installation

⚠ WARNING

SOUND HAZARD—All effective sirens and horns produce loud sounds (120 dB) that may cause permanent hearing loss. Always minimize your exposure to the sound of the siren and horn and wear hearing protection. Do not sound the siren or horn indoors or in enclosed areas where you and others will be exposed to the sound.

⚠ WARNING

LIGHT HAZARD—To be an effective warning device, an emergency warning system produces bright light that can be hazardous to your eyesight when viewed at a close range. Do not stare directly into the lights at a close range or permanent damage to your eyesight may occur.

After testing the installation, test the emergency warning system to ensure that it is operating properly. Also test all vehicle functions, including horn operation, vehicle safety functions, and vehicle lighting systems to ensure proper operation. Ensure that the installation has not affected the vehicle operation or changed any vehicle safety functions or circuits. After testing is complete, provide a copy of these instructions to the instructional staff and all operating personnel.

Do not test the sound and light system of the vehicle while driving. Operating the vehicle warning systems may pose a hazard to the operator and other drivers if the systems do not function as expected. Test the vehicle only in a controlled environment.

CHAPTER 5

Maintaining and Servicing the Valor

This chapter describe how to maintain and service the Valor lightbar. Establishing a regular maintenance and inspection schedule extends the life of the lightbar and ensures safety. For service, support, or replacement parts, contact the Federal Signal Service Department at 1-800-433-9132, 7 a.m. to 5 p.m., Monday through Friday (CT). See Table 5.2 on page 41 for replacement parts and part numbers.

⚠ WARNING

SHOCK HAZARD—*Disconnect ALL power to the lightbar before any maintenance is performed. Failure to do so may result in property damage, serious injury, or death.*

⚠ CAUTION

BURN HAZARD—*After prolonged operation, the unit gets hot and can cause burns. Do not touch the unit while or shortly after it has been operating. Always allow the unit to cool before handling it.*

Cleaning the Lightbar Lens

⚠ WARNING

CRAZING/CLEANING SOLUTIONS—*The use of cleaning solutions, such as strong detergents, solvents, and petroleum products, can cause crazing (cracking) of the lightbar lens and reflectors. To clean the reflectors, use a soft, damp cloth. To clean the lens, use a soft cloth and a solution of water and a mild detergent.*

⚠ WARNING

CRAZING/CHEMICALS—*Crazed, cracked or faded lenses or reflectors reduce the light output and the effectiveness of the lighting system. A lens or reflectors showing this type of aging must be replaced. Failure to follow this warning may result in bodily injury or death.*

To clean the lightbar lens:

1. Rinse the lens with lukewarm water to loosen dirt and debris.
2. Use a mild detergent, lukewarm water, and a soft cloth to gently clean the lens. To avoid damaging the finish, do not use heavy pressure or caustic, abrasive, or petroleum-based cleaners.
3. Rinse and dry the lens with a soft cloth to prevent water spotting.
4. To remove fine scratches and haze, use a soft cloth and a high quality automotive paste cleaner/wax that is non-abrasive.

Removing and Reinstalling the Lightbar Lens

The lightbar lens, which is the top half of the Valor housing, covers the ROC (Reliable Onboard Circuitry) PCBs and controller PCB.

Tool required:


T27 Torx driver

Removing the Lens

To remove the lens:

1. Disconnect all power to the lightbar either at the battery or at the lightbar (see “Disconnecting/Connecting Power and CAT5 at the Lightbar” on page 36).
2. Use a T27 Torx driver to remove the 1/4"-20 Torx-head barrel nuts securing the lens (Figure 5.1). Carefully remove the lens and gasket as a unit. Avoid damaging the lip seal.
3. Verify that an O-ring is under the head of each barrel nut and not stuck to the lens. Use a wooden or plastic pick to carefully remove the O-rings from the lens to prevent damaging them.
4. Inspect the O-rings and the lip seal for deformation, brittleness, cuts, or tears. To maintain watertightness, replace a questionable O-ring or seal.
5. Inspect the lens for cracks, crazing (hairline cracks) and other defects.

Figure 5.1 Locations of the barrel nuts in lens (numbers indicate tightening sequence)



Reinstalling the Lens

To reinstall the lens:

1. Reinstall the gasket and lens. To prevent cross-threading the barrel nuts, back them counterclockwise until you hear the click of the threads engaging.
2. Tighten the barrel nuts to 16-24 in-lb in the sequence shown in Figure 5.1 on page 34.

Replacing a PCB

The Valor lightbar has two front, two rear, and two end ROC PCBs as well as a controller PCB (Figure 5.2). They are configured at the factory per the customer order.

NOTICE

STATIC SENSITIVE DEVICE—This lightbar's circuitry can be damaged by electrostatic discharge (ESD). Follow anti-static procedures when servicing this lightbar.

Tool required:


T27 Torx driver

Removing a PCB

To remove a PCB:

1. Disconnect all power to the lightbar at the battery or at the lightbar (see “Disconnecting/Connecting Power and CAT5 at the Lightbar” on page 36).
2. Use a T27 Torx driver to remove the 1/4"-20 Torx-head barrel nuts securing the lens (Figure 5.1 and on page 34). Carefully remove the lens and gasket as a unit. Avoid damaging the lip seal.
3. Verify that an O-ring is under the head of each barrel nut and not stuck to the lens. Use a wooden or plastic pick to carefully remove the O-rings from the lens to prevent damaging them.

Figure 5.2 Locations of ROC PCBs



290A6564

4. Inspect the O-rings and the lip seal for deformation, brittleness, cuts, or tears. To maintain watertightness, replace a questionable O-ring or seal.
5. Note and record the connection to the PCB (Figure 5.2 on page 35), then lift it and disconnect the harnesses.
6. Remove the PCB from the lightbar.

Reinstalling a ROC PCB


To reinstall a PCB:

1. Place the new PCB in the same position as the old PCB and reconnect the harnesses.
2. Reinstall the gasket and lens. To prevent cross-threading the barrel nuts, back them counterclockwise until you hear the click of the threads engaging, then tighten them to 16-24 in-lb in the sequence shown in Figure 5.1 on page 34.
3. Reconnect power to the lightbar.

Disconnecting/Connecting Power and CAT5 at the Lightbar


A detachable weather-proof connector at the bottom of the lightbar on the passenger side enables you to quickly disconnect both power and ground together without removing the cables from the battery (Figure 5.3). The smaller waterproof connector is for the CAT5 communication cable. The connectors, each joining internal two-foot cables leading to the lightbar controller, are secured with a secondary lock that prevents disconnection unless the lock is fully disengaged. For instructions on mating and unmating the connectors, see the following pages.

Figure 5.3 Locations of watertight connectors



290A6570


Figure 5.4 Secondary lock mechanism in the plug and receptacle





Disconnecting a Cable at the Lightbar

To disconnect the power or CAT5 cable:


1. Pull back the CPA on the receptacle.



2. Fully depress the locking latch. To allow the connectors to be separated, the locking latch must be fully depressed to release the locking ramp on the plug.



Locking latch in down position: connectors cannot be unmated.




Locking latch is fully depressed: latch releases locking ramp.

3. Pull the connectors apart.


Reconnecting a Cable at the Lightbar

To reconnect the power or CAT5 cable:

1. Firmly push the connectors together until you feel them snap together and you hear a click. This tactile and audible confirmation ensures that the connectors are properly and fully mated.



2. Press the CPA towards the plug to engage the secondary lock.



Troubleshooting the Lightbar

This section provides troubleshooting assistance for common problems. If you have any questions left unanswered, call the Federal Signal Service Department at 1-800-433-9132, 7 a.m. to 5 p.m., Monday through Friday (CT).

Table 5.1 Troubleshooting tips

Problem	Corrective Action
The lightbar does not light	<ul style="list-style-type: none"> ✓ Check that the lightbar's red power line (+BAT) and the black ground- power line (–GND) are properly connected to a good, fully charged 12-volt battery. Check the 40 A fuse. ✓ Ensure that the ground connection from the lightbar controller to the aluminum extrusion is good. ✓ Check that the CAT5 cable is connected to the Serial Interface Module (J1) and there are no damaged pins in the sockets. ✓ Try a new CAT5 cable. ✓ Check the connections on the Serial Interface Module: <ol style="list-style-type: none"> 1. the black wire and the black/white wire are connected to ground (–GND) 2. the white wire is connected to 12 Vdc. Check the 1 A fuse. 3. a MODE wire has 12 Vdc ✓ Check the position of Switch 1 on SW-2 in the Serial Interface Module. If Switch 1 is down (ON), ensure that the ENABLE control wires (green/white and orange/black) have 12 Vdc applied. ✓ Check the positions of the DIP switches in the Serial Interface Module. See Figure 3.3 on page 14 and Table 3.2 on page 16. ✓ Check the fuses on the mainbar controller.
An LED module does not light	<ul style="list-style-type: none"> ✓ Swap the LED board with good board to see if the board is bad. ✓ Check the connections of the cable that goes from the lightbar controller to the LED ROC board. ✓ If it is a rear module, check the SignalMaster connections.
Half of an LED module does not light	<ul style="list-style-type: none"> ✓ Replace the ROC board that the LED is on.
The lightbar turns off when the Flash Takedown/Alley lights turn on	<ul style="list-style-type: none"> ✓ Ensure that the vehicle battery is fully charged. ✓ Check that the lightbar's red power line (+BAT) and black ground- power line (–GND) are properly connected to a good, fully charged 12-volt battery. ✓ Check the red power line (+BAT) and the black ground-power line (–GND) connections in the lightbar and vehicle.

(continued on next page).

Table 5.1 Troubleshooting tips (continued)

Problem	Corrective Action
The lightbar has a delayed response to being shut off	<ul style="list-style-type: none"> ✓ Ensure that the connections on the Serial Interface Module are kept separate from strobe supplies. ✓ Check all the ground connections, especially on the Serial Interface Module.
A Flash Takedown/Alley light stays on with ignition power applied	<ul style="list-style-type: none"> ✓ Ensure there is no voltage on the corresponding control wire. ✓ To see if the ROC board is bad, swap it with a similar board. ✓ Swap the cables on the lightbar controller outputs with a known good output. If the problem moves to another halogen light, send the lightbar controller to Federal Signal for repair.
Takedown/alley lights work, but Flash Takedown/Alley lights do not work	<ul style="list-style-type: none"> ✓ Ensure that 12 Vdc is applied to the takedown and alley (red/black) control wire. ✓ Check the 12 Vdc power and negative ground connections to the lightbar to ensure there is enough current.
Only one takedown light turns on	<ul style="list-style-type: none"> ✓ Check the connections from the lightbar controller to the ROC boards and ensure they are in the proper locations.
SignalMaster LEDs do not light	<ul style="list-style-type: none"> ✓ Check the jumper and switch settings on the Serial Interface Module. Ensure they are both set for the correct operation. See Figure 3.3 on page 14 and Table 3.1 on page 15. ✓ Ensure that Switch 4 on SW-2 is in the correct position for the selected operation on the Serial Interface Module and ignition power was removed and reapplied. ✓ Check the connections at the SignalMaster controller. If the controller is a model SS2000SM, ensure that the connector has power and the ground is connected to pins 10 and 11 on the SignalMaster plug.

Replacement Parts

This section contains a partial list of replacement parts. To order replacement parts, call the Federal Signal Service Department at 800-433-9132, 7 a.m. to 5 p.m., Monday through Friday (Central Time) or contact your nearest distributor.

Table 5.2 Replacement parts

Description	Part Number
PCB Assembly End (Configured)	Contact Factory
PCB Assembly, Front (Configured)	Contact Factory
PCB Assembly, Rear (Configured)	Contact Factory
PCB Assembly, Controller (Configured)	Contact Factory
Nut, 1/4-20, Barrel	7065071
Seal, Lip, Lens	8651116
O-Ring, Lens Nut	7067016
Gasket, Lens	8651125
Lens, Clear, 44"	8651101
Lens, Clear, 51"	8651103

Getting Technical Support and Service

For technical support and service, please contact:

Federal Signal Corporation
 Service Department
 Public Safety Systems
 Phone: 1-800-433-9132
 Fax: 1-800-343-9706
 Email: empserviceinfo@fedsig.com

Returning a Product to Federal Signal

Before returning a product to Federal Signal, call 800-264-3578, 800-433-9132, or 800-824-0254 to obtain a Returned Merchandise Authorization number (RMA number). To expedite the process please be prepared with the following information:

- Your Federal Signal customer or account number.
- The purchase order number under which the items were purchased.
- The shipping method.
- The model or part number of the product being returned.
- The quantity of products being returned.
- Drop ship information as needed.
- Any estimate required.

When you receive your RMA Number:

- Write the RMA number on the outside of the box of returned items.
- Reference the RMA number on your paperwork inside of the box.
- Write the RMA number down, so that you can easily check on status of the returned equipment.

Send all material with the issued RMA Number to:

Federal Signal Corporation
Public Safety Systems
2645 Federal Signal Drive
University Park, IL 60484-3167
Attn: Service Department
RMA: # _____
www.fedsig.com

CHAPTER 6

Wiring Schematics

This chapter has schematics showing the Valor lightbar with typical connections to these controllers:

- SignalMaster controller (external control)
- SW400SS Switch Module (internal control)
- SmartSiren Model SS2000SM
- Non-SignalMaster
- PA640

Figure 6.1 Typical connections with a SignalMaster controller (external control)




Figure 6.2 Typical connections with a SW400SS Switch Module (internal control)




Figure 6.3 Typical connections with a SmartSiren Model SS2000SM controller




Figure 6.4 Typical connections with a non-SignalMaster controller





Figure 6.5 Typical connections with a PA640 controller





2645 Federal Signal Drive, University Park, IL 60484-3167
Tel.: (800) 264-3578 • Fax: (800) 682-8022
www.fedsig.com

© 2011 Federal Signal Corporation