

USER MANUAL



LR51100 SERIES

LiFePO₄ (LFP) Battery

LR51100A
LR51100B
LR51100E

Contents

1	Important Safety Instructions	01
2	General Information	02
2.1	Appearance	02
2.2	Product size	08
3	Basic Information	09
3.1	Interface definition	09
3.2	Product features	10
3.3	LCD color touch display instructions	11
3.4	LED indication	14
4	Instructions	16
4.1	Packing list	16
4.2	Installation requirements	17
4.3	Charging operation	21
4.4	Discharge operation	21
4.5	Reset button instructions	21
4.6	Description of battery parallel capacity and voltage	22
5	Protection Features	23
6	Specifications	27
7	Precautions	28
8	Disclaimers	28

1 Important Safety Instructions

- * Thank you for choosing EPEVER Lithium Iron Phosphate (LFP) battery, please read this manual carefully before using this product.
- * It is strictly forbidden to install this product in harsh environments such as moisture, salt spray, corrosion, greasy, flammable and explosive, or a large amount of dust accumulation.
- * Please keep this product manual for future reference.

Precautions for work and storage

- a) Please keep the battery in a cool, dry place. The environment should be free of corrosive, explosive and insulation-damaging gases or conductive dust, and away from fire and heat sources and high pressure; It is forbidden to immerse the battery in water; Keep out of reach of children; Pay attention to anti-static electricity (static electricity may damage the battery protection circuit, causing battery damage).
- b) The battery should be safely fixed in a reasonable use of the environment, the connector must be reliably connected to avoid contact friction caused by arc and sparks.
- c) When handling the battery, please handle it gently to avoid mechanical vibration, collision and pressure shock. Otherwise, it may cause internal short circuit of the battery, resulting in high temperature and fire.
- d) Do not short-circuit the positive and negative poles of the battery, and do not disassemble or assemble the battery to avoid danger.
- e) Please keep the battery in a semi-charged state (40%~80% SOC is appropriate). Please wrap the battery with non-conductive materials to avoid direct metal contact with the battery, which may cause battery damage.
- f) Please dispose of waste batteries safely and properly, and do not put them into fire or liquid.
- g) This battery cannot be used in series.

Danger warning

- a) It is strictly forbidden to crush, drop, collide, puncture, burn and other destructive behaviors on the battery.
- b) It is forbidden to disassemble and assemble the battery. Improper disassembly and assembly may damage the protective function of the battery, resulting in deformation, heating, smoke or combustion of the battery.
- c) It is forbidden to short circuit the battery. It is prohibited to connect the positive and negative electrodes of the battery with conductive materials; Do not store or transport the battery with the conductor to avoid battery damage due to short circuit.
- d) It is forbidden to heat and incinerate batteries. It may melt battery components, lose safety features, or burn electrolyte. Overheating can deform, heat, smoke, or burn the battery.


Emergency treatment method

- a) When the electrolyte leaks, avoid skin and eye contact with the electrolyte. In case of contact, wash immediately with plenty of water and seek help from a doctor. It is forbidden for any person or animal to swallow any part of the battery or the substances contained in the battery.
- b) If the battery is seriously deformed or the electrolyte leaks due to collision and extrusion, the battery should be placed in the explosion-proof box or an open place, and the personnel should be evacuated quickly if conditions permit.
- c) If the battery catches fire during use or storage, use a high-pressure water cannon to extinguish the fire under the condition of ensuring personal safety.
- d) If the battery catches fire during charging, be sure to turn off the charger as soon as possible before executing the next fire extinguishing action.

2 General Information

2.1 Appearance


2.1.1 LR51100A




Front



Top




Side




A&K	Battery rack fixed ears	F	LCD
B&L	Handle	G	Switch
C	Inverter communication interface	H	Negative connector
D	Parallel communication interface	I	Positive connector
E	Reset switch	J	Grounding terminal


2.1.2 LR51100B




Front



Top




Side




A&L	Battery rack fixed ears	H	Negative connector
B&K	Handle	I	Positive connector
C	Battery SOC indicator	J	Circuit breaker
D	Inverter communication interface	M	Grounding terminal
E	Parallel communication interface	N	Run indicator
F	Reset switch	O	Alarm indicator
G	Switch		


2.1.2 LR51100E




Front



Top




Side




A&K	Fixing ears	G	Switch
B&J	Handle	H	Negative connector
C	Battery SOC indicator	I	Positive connector
D	Inverter communication interface	L	Grounding terminal
E	Parallel communication interface	M	Run indicator
F	Reset switch	N	Alarm indicator


2.2 Product size



Front



Top



Side


Note: The LR5100A/B/E have the same outline dimensions.

3 Basic Information

3.1 Interface definition

(1)The pin definitions of the BMS communication interface are as follows. The RJ45 communication interface is used for connecting the lithium battery to an inverter or a PC.


Pin No.	Rj45 Definition
1	RS485-B1
2	RS485-A1
3	ISO_GND
4	CAN1-H
5	CAN1-L
6	ISO_GND
7	RS485-A1
8	RS485-B1



(RJ45)(BMS)

(2)The pin definitions of the IP-IN communication interface are as follows. The RJ45 communication interface is used for parallel communication between lithium batteries.


Pin No.	RJ45 Definition
1	CAN-H2
2	CAN-L2
3	ISO_GND
4	DO+
5	DO-
6	ISO_GND
7	CAN-L2
8	CAN-H2



(RJ45)(IP-IN)

(3)The pin definitions of the IP-OUT communication interface are as follows. The RJ45 communication interface is used for parallel communication between lithium batteries.

Pin No.	RJ45 Definition
1	CAN-H2
2	CAN-L2
3	ISO_GND
4	DI+
5	DI-
6	ISO_GND
7	CAN-L2
8	CAN-H2







3.2 Product features

- It has the function of single voltage and overall voltage detection, over-voltage and under-voltage alarm and protection.
- It has the functions of charge and discharge current detection, alarm and protection.
- It has the function of cell, environment and PCB temperature detection, and can alarm and protect when charging and discharging at high and low temperature.
- It has the function of detection and protection of output short circuit.
- With the battery SOC calculation, charge and discharge cycle calculation function.
- With a charge balancing function, reduce the charging current of the high-voltage cell (the reduced current is the balance current set by the BMS).
- With LCD indicator function, indicating the current battery SOC, battery fault status, operating status, etc.
- BMS manual and automatic sleep function.
- With charge current limiting function.
With history storage function (not less than 500 storage capacity).
- With RS485 communication function, real-time monitoring of BMS and battery status.
- The two-stage over-current protection function of discharge has different response speed to different current values, which protects the battery more reliably.


3.3 LCD color touch display instructions

- Interface introduction:
- Main interface:



Serial Number	Icon	Icon Meaning
1		Main Interface Icon. Click to directly enter the main interface.
2		Alarm Display Button. Click to enter the alarm interface. If there is an alarm, this icon will blink.
3		Parameter Setting Icon. Click to enter the settings interface.
4		Slave Device Interface Access Button. If no slave device is present, it enters the cell voltage and temperature display interface.

- Slave interface



A: Button to Return to Previous Interface

B: Select Slave Parameters

C: Slave SOC Display Area

D: Slave Voltage, Current, and Capacity Display Area

E: Slave Temperature or Cell Voltage Display Area

F: Button to Switch Between Slave Cell Voltage and Temperature Display

Note: If no parallel slave device is connected, all the above areas will display master device parameters.

- Parameter settings

Click the settings icon on the main interface to enter the parameter settings interface, as shown below:



The parameter settings interface allows you to configure the language, display screen sleep time, temperature unit, and communication protocol.

Notes:

- a. The "About This Device" section is a display program and cannot be modified.
- b. To prevent accidental touch, after entering the relevant settings interface and selecting the parameter to be configured, do not directly click the button to return to the main interface. Instead, click the button to return to the previous interface to verify whether the setting is accurate.







B. Communication Protocol Selection

The protocol setting is used to select the communication protocol between the BMS and the inverter:



Note: If the red box area in the figure above does not display a specific protocol, please wait for approximately 10 seconds for the data to buffer. (Note: Normal communication is required for buffering to occur.)

3.4 LED indication

Status	RUN LED	Alarm LED	Battery Indicator LED				Instructions
							
Power Off/Sleep	Off	Off	Off	Off	Off	Off	standby state
standby state	Flash 1	Off	Display based on the real-time status of the current State of Charge (SOC).				Secondary protection has been triggered. Connect the host computer to check the fault information and take appropriate measures.
	Flash 1	Flash 3					
Charge	on	off	Display based on the real-time status of the current State of Charge (SOC).				Normal charge
	on	Flash3					Over-charge alarm please unplug the charger
	on	off	on	on	on	on	Overcharge protection; If the charger is unplugged, the indicator turns to standby state.
Discharge	Flash3	off	Display based on the real-time status of the current State of Charge (SOC).				Normal discharge
	Flash3	Flash3					Over-discharge protection, please charge the battery.
	off	off	off	off	off	off	Enter undervoltage sleep state, please charge the battery
Failure state	off	on	off	off	off	off	The LED indicates a protection mode (e.g., overtemperature, overcurrent, or short circuit), during which charging and discharging are disabled. Please troubleshoot the cause.

Note: When the charging current limit is triggered, the status of the charging overcurrent protection will be released, and at this time, the indicator light status will switch to the

LED Flash Instructions:

Flash mode	on	off
Flash 1	0.25S	3.75S
Flash 2	0.5S	0.5S
Flash 3	0.5S	1.5S











SOC Instructions:

SOC	Charging				Discharge				Standby state			
	L4	L3	L2	L1	L4	L3	L2	L1	L4	L3	L2	L1
0~25%	off	off	off	Flash 2	off	off	off	on	off	off	off	on
25~50%	off	off	Flash 2	on	off	off	on	on	off	off	on	on
50~75%	off	Flash 2	on	on	off	on	on	on	off	on	on	on
75~100%	Flash 2	on	on	on	on	on	on	on	on	on	on	on

4 Instructions

4.1 Packing list

Before unpacking, please check the outside of the battery for damage to the packaging and check the model of the battery. If there is any abnormality, please do not open the package and contact the after-sales service center as soon as possible. After unpacking the battery, please check whether the product is complete according to the packaging information. If you have any questions, please contact the after-sales service center as soon as possible.



















 <p>X1 Lithium battery</p>	 <p>X2 Battery rack fixed ears</p>	 <p>X1 Rs485 communication cable</p>	 <p>X1 Battery pack parallel communication cable</p>
 <p>X1 Communication cable for PC</p>	 <p>X2 RNB22-8S wiring harness</p>	 <p>X2 RNB22-6S wiring harness</p>	 <p>X1 RJ45 plug with terminal resistance(@120Ω)</p>
 <p>X1 RJ45 plug</p>	 <p>X2 M8X12 bolt</p>		

4.2 Installation requirements

c.Installation environment


- The battery works best at 20~40°C.
- Avoid installation in environments with direct high temperature and rain.
- Avoid installation close to high temperature heat source or low temperature cold source.
- Avoid installation in places where the ambient temperature changes drastically.
- Avoid installation in strong interference environments.
- Avoid installation in places where children can enter.
- Avoid installation in places where water is likely to accumulate.
- It is forbidden to place flammable and explosive materials around the equipment.

d.Prepare tools

 <p>Hammer Drill</p>	 <p>Rubber Hammer</p>	 <p>Claw Safety Hammer</p>	 <p>Insulated Cross Screwdriver</p>	 <p>Insulated Slotted Screwdriver</p>
 <p>Spirit Level</p>	 <p>Tape Ruler</p>	 <p>Insulation Tape</p>	 <p>Dustproof Cover</p>	 <p>Protective Glasses</p>
 <p>Utility Knife</p>	 <p>Wire Stripper</p>	 <p>Diagonal Pliers</p>	 <p>MC4 Crimper</p>	 <p>Multimeter</p>
 <p>AC/DC Clamp-On Ammeter</p>	 <p>Marker Pen</p>	 <p>Electric Screwdriver</p>		


e.Wiring diagram

- Connect to the inverter



- Positive output power cable
- Negative output power cable
- CAN/RS485 communication cable (1200mm)

• Connect in parallel



- Positive output power cable
- Negative output power cable
- CAN/RS485 communication cable (1200mm)
- Lithium battery positive parallel power cable
- Lithium battery negative parallel power cable
- Lithium battery parallel communication cable (OUT~IN) (280mm)

Precautions for inverter connection and parallel connection:

According to the above parallel schematic diagram and 2.1 products appearance, select the correct wiring harness for connection.

1. Output power cable (black and red cables): The positive connector of the host is connected to the positive terminal of the inverter (red cable); The negative connector of the host is connected to the negative terminal of the inverter (black cable).
2. CAN/RS485 communication cable (blue cable): Communication between the host and the inverter. The interface of the host is BMS port, and the terminal port of the inverter is BMS port.
3. Lithium battery parallel power cable: The positive connector of the host is connected to the positive connector of the slave (orange cable); The negative connector of the host is connected to the negative connector of the slave (grey cable).
4. Lithium battery parallel communication cable (green cable): The IP-OUT communication interface of the first battery pack connects to the IP-IN communication interface of the second battery pack. The IP-OUT communication interface of the second battery pack connects to the IP-IN communication interface of the third battery pack, and so on.

(Note: The first battery pack serves as the host and is connected to the inverter.)

Warning

1. For operational safety and compliance, please disconnect the communication and cable link with the inverter when storing the battery.
2. During the handling and installation of the battery, it is recommended to wear safety helmets, goggles, protective shoes and other safety equipment suitable for the work to prevent accidental injury.
3. All wiring must be carried out by professionals. With the right cables, the battery connection is essential for the safe and efficient operation of the system. In order to reduce the risk, please use the cable provided by our company, or our recommended cable specifications.

4.3 Charging operation

1. Check before charging.

- Inspect the appearance of the battery and inverter or other connected equipment to ensure that the power cord and all wiring harnesses are connected.
- Make sure the power supply meets the specification requirements for the battery

2. Turn off the inverter or other equipment, connect the positive and negative terminals of the battery, and connect the communication cable normally.

⚠ Warning: Before connecting the battery, ensure that the positive and negative terminals are connected. Do not reverse connect.

3. Connect the charger to the battery's positive and negative terminals; then turn on the charger.

4. Press the battery's power switch to turn on the battery, and normal charging will begin.

● **Standard Charging:**

First, charge the battery to 57.6V with a constant current of 20A (0.2C), and then charge to 5A (0.05C) with a constant voltage of 57.6V.

Note: All tests stated in this document shall be performed at 25±2°C.

4.4 Discharge operation

1. Before discharging, check whether the load and equipment are turned off.

2. Properly connect the positive and negative terminals of the battery to the load/inverter or other equipment.

⚠ Warning: Before connecting the load and equipment, please confirm the positive and negative wiring of the battery, and prohibit reverse connection.

3. Turn on the load/inverter or other device.

4. Press the battery's power switch to turn on the battery, and normal discharging will begin.

● **Standard discharge:**

After the battery is standard charged, discharging the battery with a constant current of 20A (0.2C) till the battery voltage drops to 41.6V.

Note: All tests stated in this document shall be performed at 25±2°C.

⚠ **Precautions for charging and discharging operation:**

a) When the temperature is high ($\geq 35^{\circ}\text{C}$) in summer, the battery should not be charged more than 0.5C during the day, and it is recommended to stand for more than 30 minutes in the middle of the charge-discharge conversion to avoid the battery being used often in a high-temperature environment (a high-temperature environment will affect the battery life).

b) When the temperature is low ($< 0^{\circ}\text{C}$) in winter, the depth of battery discharge $< 70\%$ to avoid over-discharge of the battery caused by too low temperature and affect the battery life.

⚠ Warning: This lithium battery should only be used with a manufacturer or manufacturer-matched compatible inverter or other equipment. When the lithium battery does not communicate with the inverter or other equipment, it is forbidden to use the lithium battery.

4.5 Reset button instructions

1. When the BMS is in sleep state, press and release the button. The protection board is activated, and the LED indicators light up in sequence starting from the "RUN" indicator, with the entire process taking 0.5 seconds.

2. When the BMS is in an active state, press and hold the button for 3–6 seconds, then release it. The protection board enters sleep mode, and the LED indicators light up in sequence starting from the lowest charge indicator, with the entire process taking 0.5 seconds.

3. When the BMS is in the active state, press and hold the key for 6–10 seconds, then release it. The protection board is reset, and all the LED lights turn off at the same time.

4. When the BMS is in the active state, press the button three times within 5 seconds, and the BMS will automatically re-address itself.

4.6 Description of battery parallel capacity and voltage

Capacity	Number of battery parallel groups	Maximum charging voltage	Discharge cut-off voltage
200Ah	2 groups	57.6V	41.6V
100Ah*n	$n \leq 32$	57.6V	41.6V

5 Protection Features

NO.	Test Content			Default Parameters	Unit
				LiFePO4	
1	Charge&Discharge and Equalization	Discharge	Rated discharge current	100	A
			Charge	Charge voltage	58.4
		Rated charging current		100	A
		After overcharging, update SOC to 100%, and allow charging again when SOC < 96% or there is discharge current.			
		Passive Equalization Function	Balance turn-on voltage	3.4	V
			Equalize the opening voltage difference	20	mV
			Balance current	150±30	mA
Balancing activation conditions 1.Reach the set balanced opening voltage difference. 2.Reach the set balanced start voltage.					
2	Over-Charge Protection	Single Cell Over-Charge Level1	Over-charge alarm voltage	3.55±0.05	V
			Over-charge alarm delay	1±0.8	S
			Over-charge alarm release voltage	3.5±0.05	V
		Single Cell Over-Charge Level2	Single cell over-charge protection voltage	3.65±0.05	V
			Single cell over-charge protection delay	1±0.8	S
			Over-charge protection release voltage	3.38±0.05	V
		Single Cell Over-Charge Level3	Single cell over-charge protection voltage	3.7±0.05	V
			Single cell over-charge protection delay	1±0.8	S
			Over-charge protection release voltage	3.65±0.05	V
		Overall Overcharge Level1	Overcharge alarm voltage	56.8	V
			Overcharge alarm delay	1±0.8	S
			Overcharge alarm release voltage	56	V
		Overall Overcharge Level2	Overcharge protection voltage	58.4	V
			Overcharge protection delay	1±0.8	S
			Overcharge protection release voltage	54	V
		Overall Overcharge Level3	Overcharge protection voltage	59.2	V
			Overcharge protection delay	1±0.8	S
			Overcharge protection release voltage	58.4	V
		Other Conditions of Release	SOC release threshold	<96%	
			Discharge current release	>2	A

3	Over-Discharge Protection	Single Cell Over-Discharge Level 1	Single cell over-discharge alarm voltage	2.9±0.05	V
			Single cell over-discharge alarm delay	1±0.8	S
			Single cell over-discharge alarm release voltage	2.95±0.05	V
		Single Cell Over-Discharge Level 2	Single cell over-discharge protection voltage	2.7±0.05	V
			Single cell over-discharge protection delay	1±0.8	S
			Over-discharge protection release voltage	2.95±0.05	V
			If the over-discharge protection cannot be restored after 30 seconds, the system will enter sleep mode.		
		Single Cell Over-Discharge Level 3	Single cell over-discharge protection voltage	2.6±0.05	V
			Single cell over-discharge protection delay	1±0.8	S
			Over-discharge protection release voltage	2.8±0.05	V
		Total Voltage Over-Discharge Level 1	Overall over-discharge alarm voltage	46.4	V
			Overall over-discharge alarm voltage delay	1±0.8	S
			Overall over-discharge alarm release voltage	47.2	V
		Total Voltage Over-Discharge Level 2	Overall discharge protection voltage	43.2	V
			Overall discharge protection delay	1±0.8	S
			Discharge protection release voltage	47.2	V
			If the over-discharge protection cannot be restored after 30 seconds, the system will enter sleep mode.		
		Total Voltage Over-Discharge Level 3	Overall discharge protection voltage	41.6	V
			Overall discharge protection delay	1±0.8	S
			Discharge protection release voltage	44.8	V
		4	Over-Current Protection	Discharge Over-Current	Discharge over-current level 1 alarm current
Discharge over-current level 1 alarm delay	1±0.8				S
Discharge over-current level 2 protection current	110±3				A
Discharge over-current level 2 protection delay	1±0.8				S
Discharge over-current level 3 protection current	150±5				A
Discharge over-current level 3 protection delay	1±0.8				S
Release condition: 1. The lock will be automatically unlocked after 1 minute. If the lock occurs for 10 consecutive times, the lock will not be automatically unlocked 2. Charge release: charging current > 1A; Release is triggered when either condition is met.					
Charge Over-Current	Charge over-current level 1 alarm current			105±3	A
	Charge over-current level 1 alarm delay			1±0.8	S
	Charge over-current level 2 protection current			110±3	A

			Charge over-current level 2 protection current	1±0.8	S
			Charge over-current level 3 protection current	150±5	A
			Charge over-current level 3 protection delay	1±0.8	S
			Release condition 1. The lock will be automatically unlocked after 1 minute. If the lock occurs for 10 consecutive times, the lock will not be automatically unlocked 2. Discharge release: discharge current > 1A		
5	Short Circuit Protection	Short Circuit Protection	Short-circuit protection current	500	A
			Short-circuit protection delay	50	US
			Short-circuit protection release: Remove Load release/charge release		
6	High Temperature Protection	Charging High Temperature	High temperature level1 alarm	60±2	°C
			High temperature level1 alarm delay	1±0.8	S
			High temperature level1 alarm release	55±2	°C
			High temperature level2 protection	65±2	°C
			High temperature level2 protection delay	1±0.8	S
			High temperature level2 protection release	60±2	°C
			High temperature level3 protection	70±2	°C
			High temperature level3 protection delay	1±0.8	S
		Discharge High Temperature	High temperature level1 alarm	60±2	°C
			High temperature level1 alarm delay	1±0.8	S
			High temperature level1 alarm release	55±2	°C
			High temperature level2 protection	65±2	°C
			High temperature level2 protection delay	1±0.8	S
			High temperature level2 protection release	60±2	°C
			High temperature level3 protection	70±2	°C
			High temperature level3 protection delay	1±0.8	S
7	Low Temperature Protection	Charge Low Temperature	Low temperature level1 alarm	5±2	°C
			Low temperature level1 alarm delay	1±0.8	S
			Low temperature level1 alarm release	10±2	°C
			Low temperature level2 protection	0±2	°C
			Low temperature level2 protection delay	1±0.8	S

			Low temperature level2 protection release	5±2	°C		
			Low temperature level3 protection	-5±2	°C		
			Low temperature level3 protection delay	1±0.8	S		
			Low temperature level3 protection release	0±2	°C		
					Low temperature level1 alarm	-15±2	°C
					Low temperature level1 alarm delay	1±0.8	S
					Low temperature level1 alarm release	-10±2	°C
					Low temperature level2 protection	-20±2	°C
					Low temperature level2 protection delay	1±0.8	S
					Low temperature level2 protection release	-15±2	°C
					Low temperature level3 protection	-25±2	°C
					Low temperature level3 protection delay	1±0.8	S
					Low temperature level3 protection release	-20±2	°C
8	Environment Temperature Protection	Environment Temperature	High temperature alarm	55±2	°C		
			High temperature protection	60±2	°C		
			High temperature protection release	55±2	°C		
9	MOS Temperature Protection		High temperature alarm	90±2	°C		
			High temperature alarm release	85±2	°C		
			High temperature protection	115±2	°C		
			High temperature protection release	85±2	°C		
10	Voltage Difference Alarm		Voltage difference level 1 alarm	0.3	°C		
			Voltage difference level 1 alarm release	0.25	°C		
			Voltage difference level 2 alarm	0.5	°C		
			Voltage difference level 2 alarm release	0.45	°C		
			Voltage difference level 3 alarm	1	°C		
			Voltage difference level 3 alarm release	0.8	°C		
11	Temperature Difference Alarm		Temperature difference level 1 alarm	10±2	°C		
			Temperature difference level 1 alarm release	7±2	°C		
			Temperature difference level 2 alarm	15±2	°C		
			Temperature difference level 2 alarm release	12±2	°C		
			Temperature difference level 3 alarm	20±2	°C		
			Temperature difference level 3 alarm release	15±2	°C		

6 Specifications

Single Battery Pack Specifications

Parameter	LR51100A	LR51100E	LR51100B
Battery Type	LiFePO4		
Nominal Voltage	51.2V		
Nominal Capacity	100Ah		
Energy	5120Wh		
Charge Cut-off Voltage	57.6V		
Discharge Cut-off Voltage	41.6V		
Maximum Charge Current	100A		
Maximum Discharge Current	100A		
Recommend Discharge Current	50A		
Cycle Life	>6000 times (0.5C charge&discharge 80%DOD @25°C)		
Function	Optional :Bluetooth/WIFI/Heating		Breaker Optional: Bluetooth /WIFI/Heating/ Aerosol fire suppression module
Communication	RS485 CAN		
Display	LCD	LED	
Number of parallel connections	Max 32 battery packs in parallel		
Certification	UN38.3 MSDS IEC62619 ROHS CE		
Operating Temperature Range	Charge: 0°C~+50°C Discharge: -20°C~+50°C		
Storage Temperature Range	-5°C~+0°C/35°C~+45°C (≤2months); 5°C~+35°C (≤3 months, Optimum storage temperature); 15°C~+35°C (≤6 months)		
Recommended Storage Humidity	40%~80%		
Terminal	M8		
Dimension (L x W x H)	476mmx450mmx136mm		
Net Weight	43.9±1kg		
IP Class	IP21		
Warranty	See lithium battery limited warranty		

1. Repeat the operation method of standard charging and standard discharge 3 times, and take the third result as the initial capacity of the battery.
2. When the battery is stored for more than 3 months, the storage voltage should be maintained at 52~53.6V.
3. For long-term storage, charge at least once every 3 months (no less than 30 minutes@0.2C).

7 Precautions

Maintenance precautions

Item	Cycle
If the battery is not in use, it needs to be fully charged and discharged to 50%.	3 months
Check whether the wall bracket installation is loose. Please tighten the appropriate position if available.	6 months
Check the casing for damage. If damaged, please repaint or contact after-sales service center.	6 months
Check exposed wires for wear and tear. If the cable is worn, replace the appropriate cable or contact the service center.	6 months
Check for debris buildup around the battery. Clean it to prevent heat dissipation of the battery.	6 months
Check water or pests to avoid long-term intrusion and damage to the battery.	6 months

Warning

1. If you find any problems that may affect the battery or the battery and energy storage system, please contact the after-sales service department, disassembly is strictly prohibited.
2. If you find that the copper wire inside the conductive wire is exposed, please strictly prohibit touching it due to the danger of high voltage. Please contact the after-sales personnel, disassembly is strictly prohibited.
3. If there are other emergencies, please contact the after-sales personnel first, operate under the guidance of the after-sales personnel, or wait for the after-sales personnel to operate on site.

8 Disclaimers

The warranty does not apply to the following conditions:

- Damage caused by improper use or inappropriate environments (It is strictly forbidden to install the Energy Storage System in the humid, salt spray, corrosive, greasy, flammable, explosive, dust accumulative or other harsh environments).
- The actual current/voltage/power exceeds the limit value of the Energy Storage System.
- Damage caused by working temperature exceeding the rated temperature range.
- Electric arc, fire, explosion and other accidents caused by failure to follow the Energy Storage System labels or manual instructions.
- Unauthorized disassembly and maintenance of the Energy Storage System.
- Damage caused by force majeure such as lightning strikes, rainstorms, mountain torrents and Utility failures.
- Damage occurred during transportation or loading/unloading the Energy Storage System.
- Serious battery discharge due to long-term storage and lack of maintenance.
- Faulty battery connection or short circuit resulting in BMS damage.



HUIZHOU EPEVER TECHNOLOGY CO., LTD

Beijing Service Hotline: 010-82894896/82894112

Huizhou Service Hotline: 0752-3889706

Shenzhen Service Hotline: 0755-89236770

E-mail: sales@epever.com

Website: www.epever.com.cn