

Programar datos de servidor

NOVIT

0000,A21,2,104.130.217.154,7040,internet.itelcel.com,webgprs,webgprs2002

EPCOMGPS

0000,A21,1,193.193.165.165,20261,internet.itelcel.com,webgprs,webgprs2002

0000,A21,Connection mode,IP address,Port,APN,APN user name,APN password

IMEI,A21,OK

Connection mode = 0: function disabled.

Connection mode = 1: function enabled; use the TCP/IP reporting mode.

Connection mode = 2: function enabled; use the UDP reporting mode.

Modificar APN – A81 GPRS

A81,internet.itelcel.com,webgprs,webgprs2002

Tiempo de reporte 0000,A12,6 //el valor que se coloque se multiplica por 10 segundos, en este caso el tiempo de reporte será de 1 minuto

Tiempo de reporte motor apagado 0000,A15,120 // el valor que se coloque se multiplica por 10 segundos, en este caso reportaría cada 20 minutos con motor apagado

Cambio de rumbo 0000, A13, 45 en este caso cada 45 grados

Paro de motor 0000, c01, 0,11111 o

Activación motor 0000, c01, 0,00000

Reporte por distancia 0000, a14, 500 en este caso cada 500m

Llamada espía 0000, a72,tel 1,tel 2

SOS 0000,a71,tel1,tel2

Cambiar password 0000, f20,password nuevo

A00 Real-Time Location Query All

A02 Track by Time Interval (SMS) All

A10 Real-Time Longitude and Latitude Query All

A12 Track by Time Interval (GPRS) All

A13 Setting the Direction Change Report Function All

A14 Track by Distance All

A15 Setting the Parking Scheduled Tracking

Function

MVT100/340/380/600/T1/MVT800/T333/T3

A16

A17 Enabling or Disabling the RFID Control OUT1

Function

MVT600/T1/T333/T3

A19 3D-Shake Wake Up MT90

A21 Setting GPRS Parameters All

A22 Setting the DNS Server IP Address All (excluding T322X/T355)

A23 Setting the Standby GPRS Server All (excluding T322X)

A29 Setting a Man Down Alarm MT90

A55 Setting Roaming and Track by Time Interval All (excluding T322X/T355)

A70 Reading All Authorized Phone Numbers All

A71 Setting a Combined Function Phone Number All

A72 Setting a Listen-in Phone Number All (excluding T322X/T355/MVT340)

A73 Setting the Smart Sleep Mode All

A75 Querying the SIM Card Balance T1/MVT600/MT90/MVT340/MVT380/MVT100/T333/T3

B05 Setting a Geo-Fence All

B06 Deleting a Geo-Fence All

B07 Setting the Speeding Alarm Function All

B08 Setting the Towing Alarm Function All (excluding T322X/T355)

B21 Setting the Anti-Theft Function

MVT100/340/380/600/T1/MVT800/T333/T322X/T3/T355/

T311

B31 Turning Off the Indicator All (excluding T322X/T355)

B34 Setting a Log Interval All (excluding MVT340/T322X/T355)

B35 Setting the SMS Time Zone All

B36 Setting the GPRS Time Zone All (excluding T355)

B60

Checking the Engine First to Determine Tracker

Running Status

MVT100/380/600/T1/MVT800/T333/T3

B91 Setting SMS Event Characters All (excluding T322X)

B99 Setting Event Authorization All

C01 Output Control MVT100/340/380/600/T1/MVT800/T333/T3

C03 Setting a GPRS Event Transmission Mode All (excluding T322X/T355)

C11 SMS Display (LCD Display) MVT600/T1/T333/T3

D10 Authorizing an RFID Card MVT600/T1/T333/T3

D11 Authorizing RFID Cards in Batches MVT600/T1/T333/T3

D14 Deleting an Authorized RFID MVT600/T1/T333/T3

D15 Deleting Authorized RFIDs in Batches MVT600/T1/T333/T3

E91 Reading the Tracker Firmware Version and SN All

-Programación IP,puerto, APN,USUARIO, PASSWORD
0000,A81,2,173.203.56.14,7050,internet.movistar.mx,0,0

0000,A81,2,173.203.56.14,7050, internet.itelcel.com,webgprs,webgprs2002

-Reportes cada minuto con motor encendido y cada 20 minutos con motor apagado

-Tiempo de reporte motor encendido 0000, A12, 6
-Tiempo de reporte motor apagado 0000, A15, 120
-Para que me acepte los dos tiempos 0000, A16, 1
- Reportes cada 45 grados. 0000, A13, 45 en este caso cada 45 grados

- Reportes cada 500 metros. 0000, a14, 500 en este caso cada 500m

- programar 2 números para llamada Espía. 0000, a72,tel 1,tel 2

- Botón de pánico SMS. 0000, B01, 1, Celular1, 1

- Desconexión de alimentación principal. 0000, B02, 2,23

- Desconexión de antena GPS. 0000, B02, 2,28

- cambiar password vía SMS. 0000, f20, password nuevo

2010, A21, 2,173.203.56.14, 7050, internet.itelcel.com, 0,0 //con este mensaje se programa IP, Puerto y APN

Tiempo de reporte0000, A12, 6,0 //el valor que se coloque se multiplica por 10 segundos, en este caso el tiempo de reporte será de 1 minuto

Cambio de rumbo 0000, A13, 45 en este caso cada 45 grados

Paro de motor 0000, c01, 0,11111 o

Activación motor 0000, c01, 0,00000

Reporte por distancia 2010, a14, 500 en este caso cada 500m

Llamada espía 2010, a72,tel 1,tel 2

SOS 2010, a71,tel1,tel 2

Cambiar password 2010, f20, password nuevo

0000, B02, 1,22 //External Power On
0000, B02, 1,23 //External Power Off