



SwitchBot Wallet Finder Card

User Manual



Please read this user manual carefully before using your device.

List of Components



Safety Information

- Keep this product away from heat and humidity, and make sure it does not come into contact with fire or water.
- This product is a precision-based electronic product, please avoid physical damage.
- Do not fold, punch holes in, or attach foreign objects to this card.
- Do not attempt to disassemble, repair, or modify this product.
- Do not use this product where wireless devices are not allowed.
- Avoid using or storing the card in areas with strong static electricity and magnetic fields.

Preparation

You will need:

- A smartphone or tablet using Bluetooth 4.2 or later.
- The latest version of our app, downloadable via the Apple App Store or Google Play Store.
- A SwitchBot account, you can register via our app or sign in to your account directly if you already have one.



Add your Wallet Finder Card to our app

Open our app and sign in. Tap the "+" icon in the top right-hand corner of the home page, choose Add Device, select the Wallet Finder Card icon, and follow the prompts to add your device.

Use with Apple's Find My app

1. Open the Find My app, then click the "+" icon and select Add Other Item.
2. Press and hold the button on your Wallet Finder Card for 2 seconds until you hear a beep.
3. Name your Wallet Finder Card and then tap Continue.
4. Register your SwitchBot Wallet Finder Card with your Apple ID, and click Continue.

5. Tap Finish. You can now attach the Wallet Finder Card to an item and track its location using the Find My app.



Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc.

Functions

Locate your SwitchBot Wallet Finder Card

1. You can use the Find My app to locate your Wallet Finder Card. When your device is within Bluetooth range, you can use the app to make your Wallet Finder Card beep, helping you locate it easily.
2. Alternatively, you can track the location of your Wallet Finder Card through our app. When the device is within Bluetooth range, our app can also make the Wallet Finder Card beep, making it easier to locate.

Locate your phone, even in Silent Mode

1. Enable Find My Phone via our app.
2. Locate the round button on the front of the SwitchBot Wallet Finder Card.
3. Quickly press the button twice. Two confirmation beeps will sound. If your phone is nearby, it will emit a sound to help you locate it.

Return of lost items via QR code

1. Activate Lost Mode for your Wallet Finder Card using our app.
2. Follow the prompts to input your contact information. This allows others to contact you by scanning the QR code on the card and return your belongings.

Disable Find My network

1. Locate the round button on the front of the SwitchBot Wallet Finder Card.
2. Quickly press the button five times. On the fifth press, hold the button for ten seconds. One confirmation beep will sound, followed by two beeps.

Reset card data

Press the button for more than 5 times and hold it for 15s. Your Wallet Finder Card will emit three beeps, indicating that its data has been successfully reset.

Perform serial number lookup

You can use the Find My app to learn about a Wallet Finder Card that's been misplaced or lost by its owner.

- Open the Find My app, scroll to the bottom of the Items tab, then tap Identify Found Item.
- Keep the card near your iPhone. Once your iPhone detects the Wallet Finder Card, it will appear in the list of found items. Select the Wallet Finder Card from the list.
- On the displayed page, you can connect to the card by following these steps:
 - ① Locate the round button on the front of the SwitchBot Wallet Finder Card. Quickly press the button twice. Two confirmation beeps will sound.
 - ② After successfully connecting to the Wallet Finder Card, tap Continue on Website.On the website, you can view Lost Mode message left by the owner and check the card's serial number.

Anti-Tracking Mode

1. If someone uses a Wallet Finder Card to unlawfully track you or your belongings, you will receive alerts on your Apple device (iPhone or iPad running iOS version 14.5 or above) via the Find My app.
2. A card that isn't with its owner for a period of time will emit a sound when it's moved.

NFC

This product supports Near Field Communication (NFC). If someone finds your lost item, they can tap the card with an NFC-enabled device to get your contact information. You can also add the card to your SwitchBot Keypad or Keypad Touch to help you quickly unlock your door.

Troubleshooting

Resetting factory settings

Press and hold the button on your Wallet Finder Card for 45 seconds. Your device is successfully reset once you hear 5 sound confirmations.

Wallet Finder Card connected to another Apple ID

1. If you want to use a different Apple ID with your Wallet Finder Card, ensure that the card has been removed from the Find My app associated with the previous Apple ID.
2. If you encounter this problem when you add the card for the first time, please contact us at support@switch-bot.com.

Specifications

Size: 85 × 54 × 2.5 mm (3.3 × 2.1 × 0.1 in.) **Weight:** 12 g (0.4 oz.)
Material: ABS + PC **Color:** Black
Connectivity: Bluetooth Low Energy
Operating Temperature: -10 °C to 45 °C (14 °F to 113 °F)
Operating Humidity: 10% to 90% RH
Service Life: 3 years (battery non-detachable)
Power Supply: 540 mAh non-rechargeable lithium manganese battery cell **Operating Frequency:** 13.56 MHz
Transmission Protocol: ISO14443A **Water Resistance:** IP67
System Requirements: iOS 14.0+, Android OS 5.0+

Warranty

We warrant to the original owner of the product that the product will be free from defects in materials and workmanship. Please note that this limited warranty does not cover:

1. Products submitted beyond the original limited warranty period.
2. Products on which repairs or modifying have been attempted.
3. Products subjected to falls, extreme temperatures, water, or other operating conditions outside the product specifications.
4. Damage due to natural disaster (including but not limited to lightning, flood, tornado, earthquake, or hurricane, etc.).
5. Damage due to misuse, abuse, negligence or casualty (e.g. fire).
6. Other damage that is not attributable to defects in the manufacture of product materials.
7. Products purchased from unauthorized resellers.
8. Consumable parts (including but not limited to batteries).
9. Natural wear of the product.

Contact & Support

Feedback: If you have any concerns or problems when using our products, please send feedback via our app through the Profile > Help & Feedback page.

Setup and Troubleshooting: support@switch-bot.com

Support Email: support@switch-bot.com