

Smart, Smarter than any other ID Card Printer

SMART Quick Guide



www.idp-corp.com



This printer package contains,
SMART Series ID Card Printer / Power Adaptor / Power Cord / USB Cable
Ribbon Cartridge (Included in Printer) / Quick Start Guide (this document)
Software Installation CD (Printer Driver / Design & DB Program / User Manual)

Printer Installation Process

<p>STEP 01 Open the top cover and take out the empty ribbon cartridge.</p> 	<p>STEP 02 Prepare the ribbon and the ribbon cartridge.</p> 	<p>STEP 03 Install supply core and take-up core to the holes and press the opposite sides until they click.</p> 	<p>STEP 04 Install a disposable cleaning roller in the ribbon cartridge.</p> 	<p>STEP 05 Peel the protective film off on the disposable cleaning roller.</p> 
<p>STEP 06 Install the ribbon cartridge and close the top cover.</p> 	<p>STEP 07 Open the hopper cover and load blank cards.</p> 	<p>STEP 08 Connect the power cord and USB cable.</p> 	<p>STEP 09 Insert the Installation CD into the PC.</p> 	<p>STEP 10 Click "Driver Install" to install the printer driver.</p> 
<p>STEP 11 When 'User Account Control' window is opened, click 'Yes'.</p> 	<p>STEP 12 Select "English" and Click "Next" in STEP 1. This step may take a few moments.</p> 	<p>STEP 13 Click "Next" to install the printer driver package in STEP 2.</p> 	<p>STEP 14 If the Windows security warning appears, click "Install this driver software anyway".</p> 	<p>STEP 15 Plug in your card printer. Check the printer is connected and turned on. This step may take a few moments. In case of USB connection, click "Next" and move to STEP 17. In case of Network, move to STEP 16.</p> 
<p>STEP 16 Search SMART Series printer connected on the network. Click "OK" after selecting and click "Next". If the printer is not found, please do network setting by referring to "SMART User Manual". * Default IP configuration is DHCP.</p> 	<p>STEP 17 Click "Close" after installation is completed.</p> 	<p>STEP 18 Open "Drivers and Printers" and right click on "IDP SMART Series Card Printer" and select "Printer Properties".</p> 	<p>STEP 19 Select the "General" tab and click 'Print Test Page'.</p> 	<p>STEP 20 Check the printed status of the Test Page.</p> 

Lamination Film Installation Process

<p>STEP 01 Open the top cover of Laminator.</p> 	<p>STEP 02 Refer to the install guide label in Laminator for correct installation of lamination film.</p> 	<p>STEP 03 Install take-up core to the back side of Laminator according to the install guide label.</p> 	<p>STEP 04 Install supply core to the front side of Laminator according to the install guide label.</p> 	<p>STEP 05 Close the top cover of Laminator after correct film installation.</p> 
--	--	---	--	---